



RICOH UNIVERSITY

Learning ♦ Knowledge ♦ Performance



M118/M119
SERVICE MANUAL

LANIER RICOH SAVIN

It is the reader's responsibility when discussing the information contained within this document to maintain a level of confidentiality that is in the best interest of Ricoh Americas Corporation and its member companies.

NO PART OF THIS DOCUMENT MAY BE REPRODUCED IN ANY FASHION AND DISTRIBUTED WITHOUT THE PRIOR PERMISSION OF RICOH AMERICAS CORPORATION.

All product names, domain names or product illustrations, including desktop images, used in this document are trademarks, registered trademarks or the property of their respective companies.

They are used throughout this book in an informational or editorial fashion only and for the benefit of such companies. No such use, or the use of any trade name, or web site is intended to convey endorsement or other affiliation with Ricoh products.

WARNING

The Service Manual contains information regarding service techniques, procedures, processes and spare parts of office equipment distributed by Ricoh Americas Corporation. Users of this manual should be either service trained or certified by successfully completing a Ricoh Technical Training Program.

Untrained and uncertified users utilizing information contained in this service manual to repair or modify Ricoh equipment risk personal injury, damage to property or loss of warranty protection.

Ricoh Americas Corporation

LEGEND

| PRODUCT CODE | COMPANY | | |
|--------------|-----------|------------------|-----------|
| | LANIER | RICOH | SAVIN |
| M118 | SP 3500SF | Aficio SP 3500SF | SP 3500SF |
| M119 | SP 3510SF | Aficio SP 3510SF | SP 3510SF |

DOCUMENTATION HISTORY

| REV. NO. | DATE | COMMENTS |
|----------|---------|-------------------|
| * | 01/2012 | Original Printing |
| | | |
| | | |
| | | |

M118/M119

TABLE OF CONTENTS

| | |
|--|------------|
| 1. PRODUCT INFORMATION | 1-1 |
| 1.1 SPECIFICATIONS..... | 1-1 |
| 1.2 MACHINE OVERVIEW..... | 1-2 |
| 1.2.1 COMPONENT LAYOUT..... | 1-2 |
| 1.2.2 PAPER PATH..... | 1-3 |
| 1.2.3 DRIVE LAYOUT..... | 1-4 |
| 1.3 MACHINE CONFIGURATION..... | 1-5 |
| 2. INSTALLATION | 2-1 |
| 2.1 INSTALLATION REQUIREMENTS..... | 2-1 |
| 2.1.1 ENVIRONMENT..... | 2-1 |
| 2.1.2 MACHINE LEVEL..... | 2-1 |
| 2.1.3 MACHINE SPACE REQUIREMENT..... | 2-2 |
| 2.1.4 POWER REQUIREMENTS..... | 2-2 |
| 2.1.5 INSTALLATION PROCEDURE..... | 2-2 |
| 3. PREVENTIVE MAINTENANCE | 3-1 |
| 3.1 PM INTERVALS..... | 3-1 |
| 3.1.1 PM PARTS..... | 3-1 |
| 3.1.2 YIELD COUNTER..... | 3-1 |
| Counter Reset..... | 3-2 |
| 4. REPLACEMENT AND ADJUSTMENT | 4-1 |
| 4.1 BEFORE YOU START..... | 4-1 |
| 4.2 SPECIAL TOOLS..... | 4-1 |
| 4.3 EXTERIOR COVERS..... | 4-2 |
| 4.3.1 FRONT COVER..... | 4-2 |
| 4.3.2 LEFT COVER..... | 4-3 |
| 4.3.3 REAR COVER..... | 4-5 |
| 4.3.4 RIGHT COVER..... | 4-6 |
| 4.3.5 TOP COVER..... | 4-7 |
| When installing the top cover..... | 4-7 |
| 4.4 ADF..... | 4-8 |
| 4.4.1 ADF UNIT..... | 4-8 |

| | |
|--|------|
| 4.4.2 ORIGINAL TRAY | 4-9 |
| 4.4.3 ADF FEED UNIT | 4-9 |
| 4.4.4 ADF SEPARATION PAD | 4-10 |
| 4.4.5 ADF FRONT COVER..... | 4-10 |
| 4.4.6 ADF REAR COVER | 4-11 |
| 4.4.7 ADF TOP COVER..... | 4-11 |
| 4.4.8 ADF MOTOR | 4-12 |
| 4.4.9 ORIGINAL SET SENSOR..... | 4-13 |
| 4.4.10 ADF COVER OPEN SENSOR..... | 4-14 |
| 4.4.11 ADF FEED SENSOR | 4-14 |
| 4.4.12 ADF DRIVE BOARD | 4-15 |
| 4.5 ARDF | 4-16 |
| 4.5.1 ARDF UNIT..... | 4-16 |
| 4.5.2 ORIGINAL TRAY | 4-17 |
| 4.5.3 ARDF FEED UNIT | 4-18 |
| 4.5.4 ARDF SEPARATION PAD..... | 4-18 |
| 4.5.5 ARDF FRONT COVER..... | 4-19 |
| 4.5.6 ARDF REAR COVER | 4-20 |
| 4.5.7 ARDF TOP COVER..... | 4-21 |
| 4.5.8 ARDF MOTOR..... | 4-22 |
| 4.5.9 ARDF COVER OPEN SENSOR | 4-23 |
| 4.5.10 ORIGINAL SET SENSOR/ORIGINAL REVERSE SENSOR.... | 4-24 |
| 4.5.11 ARDF FEED SENSOR..... | 4-27 |
| 4.5.12 ARDF DRIVE BOARD..... | 4-28 |
| 4.6 SCANNER UNIT | 4-29 |
| 4.6.1 OPERATION PANEL | 4-30 |
| 4.6.2 SCANNER TOP COVER | 4-31 |
| 4.6.3 SCANNER CARRIAGE UNIT | 4-32 |
| 4.6.4 EXPOSURE LAMP | 4-34 |
| When reinstalling the exposure lamp | 4-34 |
| 4.6.5 LAMP STABILIZER BOARD..... | 4-35 |
| 4.6.6 SCANNER MOTOR..... | 4-36 |
| 4.7 LASER UNIT..... | 4-37 |
| 4.7.1 CAUTION DECAL LOCATIONS | 4-37 |
| 4.7.2 LASER UNIT..... | 4-37 |
| 4.7.3 POLYGON MIRROR MOTOR | 4-38 |
| 4.8 PAPER FEED AND EXIT..... | 4-39 |
| 4.8.1 PAPER FEED ROLLER..... | 4-39 |

| | |
|--|------|
| After installing a new paper feed roller | 4-39 |
| 4.8.2 FRICTION PAD | 4-40 |
| 4.8.3 PAPER END SENSOR | 4-40 |
| 4.8.4 BY-PASS FEED ROLLER | 4-41 |
| 4.8.5 BY-PASS FEED ROLLER FRICTION PAD | 4-42 |
| 4.8.6 BY-PASS FEED SENSOR..... | 4-43 |
| 4.8.7 PAPER FEED CLUTCH..... | 4-44 |
| 4.8.8 RELAY CLUTCH | 4-45 |
| 4.8.9 REGISTRATION CLUTCH | 4-45 |
| 4.8.10 TONER END SENSOR..... | 4-46 |
| 4.8.11 PAPER EXIT SENSOR..... | 4-46 |
| 4.8.12 RELAY SENSOR | 4-47 |
| 4.8.13 INVERTER SENSOR..... | 4-47 |
| 4.8.14 REGISTRATION ROLLER AND SENSOR | 4-48 |
| 4.9 PAPER TRANSFER | 4-51 |
| 4.9.1 TRANSFER ROLLER | 4-51 |
| After installing a new transfer roller | 4-51 |
| 4.10 FUSING..... | 4-52 |
| 4.10.1 FUSING UNIT | 4-52 |
| Reinstallation..... | 4-54 |
| After installing a new fusing unit..... | 4-54 |
| 4.10.2 THERMOSTAT | 4-55 |
| 4.10.3 THERMISTOR | 4-56 |
| 4.10.4 FUSING LAMP..... | 4-56 |
| When reinstall the fusing lamp | 4-57 |
| 4.10.5 HOT ROLLER..... | 4-58 |
| 4.10.6 PRESSURE ROLLER..... | 4-58 |
| 4.10.7 HOT ROLLER STRIPPER PAWLS..... | 4-59 |
| 4.11 MOTORS | 4-60 |
| 4.11.1 MAIN MOTOR..... | 4-60 |
| 4.11.2 DUPLEX MOTOR (FOR M119) | 4-60 |
| 4.12 ELECTRICAL COMPONENTS | 4-61 |
| 4.12.1 LAYOUT OF PC BOARDS..... | 4-61 |
| USB Host Board..... | 4-61 |
| ECB (Engine Controller Board) | 4-62 |
| When installing the new ECB (Engine Controller Board)..... | 4-63 |
| EEPROM..... | 4-63 |
| Controller Board..... | 4-64 |

| | |
|--------------------------------------|------|
| FCU..... | 4-64 |
| 4.12.2 PSU..... | 4-65 |
| 4.12.3 CHARGE TERMINAL CASE..... | 4-68 |
| 4.13 OTHERS | 4-69 |
| 4.13.1 COOLING FAN | 4-69 |
| 4.13.2 SPEAKER | 4-69 |
| 4.13.3 QUENCHING LAMP | 4-70 |
| 4.14 IMAGE ADJUSTMENT..... | 4-71 |
| 4.14.1 REGISTRATION ADJUSTMENT | 4-71 |
| User Adjustment..... | 4-71 |
| Service Adjustment | 4-71 |

5. SYSTEM MAINTENANCE REFERENCE 5-1

| | |
|--|------|
| 5.1.1 OVERVIEW | 5-1 |
| 5.1.2 MAINTENANCE MODE MENU | 5-1 |
| To access Maintenance Mode do the following:..... | 5-1 |
| Selecting an Item..... | 5-1 |
| Going into the Next Level/ Returning to the Previous Level | 5-1 |
| Exiting the Maintenance Mode Menu | 5-1 |
| Menu List..... | 5-2 |
| 5.1.3 FAX SERVICE TEST MENU | 5-19 |
| Entering the Fax Service Test Menu | 5-19 |
| Selecting an Item..... | 5-19 |
| Going into the Next Level/ Returning to the Previous Level | 5-19 |
| Exiting the Maintenance Mode Menu | 5-19 |
| Menu List..... | 5-19 |
| 5.2 CONFIGURATION AND MAINTENANCE PAGE | 5-21 |
| 5.2.1 OVERVIEW | 5-21 |
| To Print the Configuration Page/ Maintenance Page | 5-21 |
| Other Types of Reports..... | 5-22 |
| Total Counter | 5-22 |
| 5.3 FIRMWARE UPDATING..... | 5-23 |
| 5.3.1 CHECKING THE MACHINE FIRMWARE VERSION..... | 5-23 |
| 5.3.2 UPDATING THE CONTROLLER FIRMWARE | 5-23 |
| Procedure..... | 5-23 |
| 5.3.3 UPDATING THE ENGINE FIRMWARE..... | 5-25 |
| Procedure..... | 5-25 |
| 5.3.4 UPDATING THE BOOT LOADER FIRMWARE..... | 5-26 |
| 5.3.5 UPDATING FAILURE | 5-26 |

| | |
|--|------------|
| 5.3.6 FW UPDATE TOOL MESSAGES | 5-27 |
| FW Update Tool Messages: Information | 5-27 |
| FW Update Tool Messages: Error | 5-30 |
| 6. TROUBLESHOOTING..... | 6-1 |
| 6.1 SERVICE CALL CONDITIONS..... | 6-1 |
| 6.1.1 SUMMARY | 6-1 |
| Fusing related SCs..... | 6-1 |
| 6.1.2 ENGINE SC | 6-2 |
| SC 2xx (Laser Optics Error) | 6-2 |
| SC 4xx (Image Transfer and Transfer Error)..... | 6-3 |
| SC 5xx (Motor and Fusing Error)..... | 6-3 |
| SC 6xx (Communication and Other Error)..... | 6-7 |
| 6.1.3 CONTROLLER SC | 6-8 |
| SC 8xx..... | 6-8 |
| 6.2 IMAGE PROBLEMS | 6-9 |
| 6.2.1 OVERVIEW | 6-9 |
| 6.2.2 TEST PAGE PRINTING..... | 6-9 |
| Test Page Print Procedure | 6-9 |
| 6.2.3 TEST PATTERN PRINTING..... | 6-10 |
| Test Pattern Print Procedure | 6-10 |
| 6.2.4 DARK LINES IN HALFTONE AREAS AT 75MM INTERVALS | 6-11 |
| 6.3 JAM..... | 6-12 |
| 6.3.1 JAM SENSOR LAYOUT | 6-12 |
| Paper Jam..... | 6-12 |
| Original Jam (AFD)..... | 6-12 |
| Original Jam (ARFD)..... | 6-13 |
| 6.3.2 JAM MESSAGE LIST | 6-14 |
| Paper Jam..... | 6-14 |
| Original Jam | 6-15 |
| 7. ENERGY SAVE | 7-1 |
| 7.1 ENERGY SAVER MODES..... | 7-1 |
| Timer Settings | 7-1 |
| Return to Stand-by Mode | 7-2 |
| Recommendation | 7-2 |
| 7.2 PAPER SAVE | 7-3 |
| 7.2.1 EFFECTIVENESS OF DUPLEX/COMBINE FUNCTION | 7-3 |
| 1. Duplex: | 7-3 |

| | |
|---------------------------|-----|
| 2. Combine mode: | 7-3 |
| 3. Duplex + Combine:..... | 7-4 |
| Total counter | 7-4 |

READ THIS FIRST

Safety Notices

Important Safety Notices

Prevention of Physical Injury

1. Before disassembling or assembling parts of the machine and peripherals, make sure that the machine power cord is unplugged.
2. The wall outlet should be near the machine and easily accessible.
3. If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
4. The machine drives some of its components when it completes the warm-up period. Be careful to keep hands away from the mechanical and electrical components as the machine starts operation.
5. The inside and the metal parts of the fusing unit become extremely hot while the machine is operating. Be careful to avoid touching those components with your bare hands.

Health Safety Conditions

Toner is non-toxic, but if you get either of them in your eyes by accident, it may cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If unsuccessful, get medical attention.

Observance of Electrical Safety Standards

The machine and its peripherals must be serviced by a customer service representative who has completed the training course on those models.

Safety and Ecological Notes for Disposal

1. Do not incinerate toner bottles or used toner. Toner dust may ignite suddenly when exposed to an open flame.
2. Dispose of used toner, the maintenance unit which includes developer or the organic photoconductor in accordance with local regulations. (These are non-toxic supplies.)
3. Dispose of replaced parts in accordance with local regulations.

WARNING

- To prevent a fire or explosion, keep the machine away from flammable liquids, gases, and aerosols. A fire or an explosion might occur.

CAUTION

- The Controller board on the MF model contains a lithium battery. The danger of explosion exists if a battery of this type is incorrectly replaced. Replace only with the same or an equivalent type recommended by the manufacturer. Discard batteries in accordance with the manufacturer's instructions and local regulations

Handling Toner

- Work carefully when removing paper jams or replacing toner bottles or cartridges to avoid spilling toner on clothing or the hands.
- If toner is inhaled, immediately gargle with large amounts of cold water and move to a well ventilated location. If there are signs of irritation or other problems, seek medical attention.
- If toner gets on the skin, wash immediately with soap and cold running water.
- If toner gets into the eyes, flush the eyes with cold running water or eye wash. If there are signs of irritation or other problems, seek medical attention.
- If toner is swallowed, drink a large amount of cold water to dilute the ingested toner. If there are signs of any problem, seek medical attention.
- If toner spills on clothing, wash the affected area immediately with soap and cold water. Never use hot water! Hot water can cause toner to set and permanently stain fabric.
- Always store toner and developer supplies such as toner and developer packages, cartridges, and bottles (including used toner and empty bottles and cartridges) out of the reach of children.
- Always store fresh toner supplies or empty bottles or cartridges in a cool, dry location that is not exposed to direct sunlight.

WARNING

- Do not use the cleaner to suck spilled toner (including used toner). Sucked toner may cause firing or explosion due to electrical contact flickering inside the cleaner. However, it is possible to use the cleaner designed for dust explosion-proof purpose. If toner is spilled over the floor, sweep up spilled toner slowly and clean remainder with wet cloth.

Laser Safety


The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.

WARNING

- Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

WARNING


- Turn off the main switch before attempting any of the procedures in the Laser Optics Housing Unit section. Laser beams can seriously damage your eyes.
- **CAUTION MARKING:**




Symbols, Abbreviations and Trademarks

This manual uses several symbols and abbreviations. The meaning of those symbols and abbreviations are as follows:

| | |
|---|-----------------|
|  | See or Refer to |
|  | Clip ring |
|  | Screw |
|  | Connector |
|  | Clamp |
|  | E-ring |
| SEF | Short Edge Feed |
| LEF | Long Edge Feed |



Short Edge Feed (SEF)



Long Edge Feed (LEF)

Trademarks

Microsoft[®], Windows[®], and MS-DOS[®] are registered trademarks of Microsoft Corporation in the United States and /or other countries.

PostScript[®] is a registered trademark of Adobe Systems, Incorporated.

PCL[®] is a registered trademark of Hewlett-Packard Company.

Ethernet[®] is a registered trademark of Xerox Corporation.

PowerPC[®] is a registered trademark of International Business Machines Corporation.

Other product names used herein are for identification purposes only and may be trademarks of their respective companies. We disclaim any and all rights involved with those marks.

PRODUCT INFORMATION

| REVISION HISTORY | | |
|------------------|------|-------------------|
| Page | Date | Added/Updated/New |
| | | None |


1. PRODUCT INFORMATION

1.1 SPECIFICATIONS

See "Appendices" for the following information:

- "General Specifications"
- "Printer"
- "Copier"
- "Scanner"
- "Fax"
- "Supported Paper Sizes"

1.2.2 PAPER PATH




[A] Duplex section (For M119)

[B] Standard paper tray unit


[C] Optional paper tray unit

1.2.3 DRIVE LAYOUT

- M118 -



- M119 -



m118d001

1. Duplex Motor


2. Main Motor

3. Registration Clutch

4. Replay Clutch

5. Paper Feed Clutch

1.3 MACHINE CONFIGURATION



| Models | Duplex Unit | Optional Memory | Optional Tray (M355) | PCL, PS | Fax | USB Host |
|--------|-------------|-----------------|----------------------|---------|-----|----------|
| (M118) | NA | NA | 250x1 | Yes | Yes | Yes |
| (M119) | Auto | NA | 250x1 | Yes | Yes | Yes |

NA: Not Available


INSTALLATION

| REVISION HISTORY | | |
|------------------|------|-------------------|
| Page | Date | Added/Updated/New |
| | | None |

2. INSTALLATION

2.1 INSTALLATION REQUIREMENTS

2.1.1 ENVIRONMENT



1. Temperature Range: 10°C to 32°C (50°F to 89.6°F)
2. Humidity Range: 15% to 80% RH
3. Ambient Illumination: Less than 2,000 lux (do not expose to direct sunlight)
4. Ventilation: 3 times/hr/person
5. Do not put the machine in areas with sudden temperature changes. This includes:
 - Areas directly exposed to cool air from air conditioning
 - Areas directly exposed to heat from a heating system.
6. Do not put the machine in areas exposed to corrosive gas.
7. Do not install the machine at locations over 2,000 m (6,562 ft.) above sea level.
8. Put the machine on a strong, level base. (Tilting towards any side must be no more than 3 mm.)
9. Do not put the machine in areas with strong vibrations.


2.1.2 MACHINE LEVEL

Front to back: Within 5 mm (0.2") of level

Right to left: Within 5 mm (0.2") of level

2.1.3 MACHINE SPACE REQUIREMENT

Put the machine near a power source with these clearances:



- A: Over 10 cm (4")
- B: Over 20 cm (7.9")
- C: Over 20 cm (7.9")
- D: Over 70 cm (27.6")

2.1.4 POWER REQUIREMENTS

⚠ CAUTION

- Make sure that the plug is tightly in the outlet.
- Avoid multi-wiring.
- Make sure that you ground the machine.

| | |
|--|--|
| Input voltage level | NA: 120 V, TW: 110 V, 60 Hz: Less than 10 A EU/ Asia/ CHN: 220 V to 240 V, 50 Hz/60 Hz: Less than 5 A |
| Permitted voltage fluctuation: 10% | |
| Do not set anything on the power cord. | |

2.1.5 INSTALLATION PROCEDURE

Refer to the "User Guide".

PREVENTIVE MAINTENANCE

| REVISION HISTORY | | |
|------------------|------|-------------------|
| Page | Date | Added/Updated/New |
| | | None |

3. PREVENTIVE MAINTENANCE

3.1 PM INTERVALS

3.1.1 PM PARTS

There are no PM parts in this machine.

Note

- Other than the three Yield Parts listed below, there are essentially no PM parts required for this product.
- These three items will need to be replaced in cases where their yield is near, however, given the ACV (Average Copy Volume) for this product, these "yield parts"^{*1} are expected to outlast the working life of the machine.

^{*1} "**Yield Parts**": Parts whose expected yield is longer than the machine lifetime when taking into consideration the machine's ACV.

| Description | Expected Yield | Q'ty/unit |
|-------------------|----------------|-----------|
| Paper Feed Roller | 120 K prints | 1 |
| Transfer Roller | 120 K prints | 1 |
| Fusing Unit | 120 K prints | 1 |

Preventive Maintenance

3.1.2 YIELD COUNTER

Yield counters for each yield part can be checked by the following methods.

Configuration Page in the "Print List/Report" menu

| Supplies Status | |
|-------------------|-------|
| Print Cartridge | ■■■■■ |
| Fuser Unit | ■■■■■ |
| Paper Feed Roller | ■■■■■ |
| Transfer Roller | ■■■■■ |

m118p001

Web Image Monitor



m118p002

Note

- The machine displays "Fuser life end notice", "Transfer roller life end notice" or "Life End of Paper Feed Roller Unit" when one of these counters reaches each yield.

Counter Reset

The process below shows how to reset the yield counters.

1. Enter the "Maintenance mode".
2. Select "Engine Maintenance", and then press "OK" key.
3. Select "Reset Fuser Unit", "Reset Transfer Unit" or "Reset Paper Feed Rol Life" and then press "OK" key.
4. Press the left key "Execute" of the "Selection keys".
5. Exit the "Maintenance mode".

REPLACEMENT AND ADJUSTMENT

| REVISION HISTORY | | |
|------------------|------|-------------------|
| Page | Date | Added/Updated/New |
| | | None |

4. REPLACEMENT AND ADJUSTMENT

4.1 BEFORE YOU START

CAUTION

- If there are printer jobs in the machine, print out all jobs in the printer buffer.
- Turn off the main power switch and unplug the machine before you do the procedures in this section.

4.2 SPECIAL TOOLS

- PC: Windows XP/Vista/7, Windows Server 2003/2003 R2, 2008/2008 R2
- USB or network cable

Note

- A computer is necessary to update the firmware.


4.3 EXTERIOR COVERS

4.3.1 FRONT COVER




m016i501

1. Pull out the standard paper tray [A].



m016i511

2. Remove two tabs [A].
3. Pull out the bypass tray [B].




m016r693

4. Open the front cover [A].

Note


- To open the front cover, push the cover release button [B] and (carefully) pull the cover forward and open (it hinges downward).



5. Push the right hinge [A] to release.
6. Front cover [B]

4.3.2 LEFT COVER

1. Front cover (☛ p.4-2)



2. Remove two screws [A] on the front side of the left cover.



3. Pull the front upper part [A] of the left cover to release the hooks.

Note

- Located outside of the cover has marks indicating the position of the hook.

Replacement and Adjustment

Exterior Covers



m016r689

4. Pull the rear upper part [A] of the left cover to release the hooks.

Note

- Located outside of the cover has marks indicating the position of the hook.




m016r690

1. Pull the front bottom part of the left cover [A] to release the hooks.

Note

- Located outside of the cover has marks indicating the position of the hook.



m016r691


2. Remove the Left cover [A].

Note

- Located outside of the cover has marks indicating the position of the hook.

Note

- There are many hooks and tabs inside the left cover. Before removing the left cover, see the images below.



Replacement
and
Adjustment

4.3.3 REAR COVER


1. Front cover (● p.4-2)
2. Left cover (● p.4-3)



3. Open the rear cover [A]
4. Slide the shaft [B] in the direction of the blue arrow, and remove the rear cover [A].

4.3.4 RIGHT COVER

1. Front cover (☛ p.4-2)
2. Rear cover (☛ p.4-5)




3. Right cover [A] (☛ x 3)

Note

- Located outside of the cover has marks indicating the position of the hook.


Note

- There are many hooks and tabs inside the right cover. Before removing the right cover, see the images below.




4.3.5 TOP COVER

1. Front cover (☛ p.4-2)
2. Left cover (☛ p.4-3)
3. Rear cover (☛ p.4-5)
4. Scanner unit (☛ p.4-29)



5. Top cover [A] (☛ x 3, ☛ x 4)

When installing the top cover




- When re-installing the top cover, always verify that the two paperweights [A] are lifted. If they are not lifted to fit into the paper slot, the paperweights [A] could be damaged.
- Make sure that these paperweights [A] can be moved smoothly (up and down) after installing the top cover. If these paperweights do not move smoothly, try installing the top cover again.

4.4 ADF

4.4.1 ADF UNIT



1. Left cover (☞ p.4-3)



2. Disconnect the ADF harness [A] (☞ x 1, ☞ x 1) and ground-wire [B] (☞ x 1).




3. Open the ADF unit [A]



4. Release the three hooks of the right hinge [A] with a screw driver, as shown above.
5. Lift the ADF unit.



4.4.2 ORIGINAL TRAY



1. Open the ADF cover [A].
2. Original tray [B] (Two tabs)

4.4.3 ADF FEED UNIT


1. Open the ADF cover.



2. Release the lock lever [A]
3. ADF feed unit [B]

4.4.4 ADF SEPARATION PAD

1. Open the ADF cover.
2. ADF feed unit (● ADF Feed Unit)




m018r661

3. ADF separation pad [A] (hook x 2, spring x 1)

4.4.5 ADF FRONT COVER

1. ADF unit (● p.4-8)
2. Original Tray (● p.4-9)
3. ADF feed unit (● p.4-9)




m018r663

m018r662

4. ADF front cover [A] (● x 1)

4.4.6 ADF REAR COVER


1. ADF unit (☛ p.4-8)
2. Original Tray (☛ p.4-9)
3. ADF feed unit (☛ p.4-9)



4. ADF rear cover [A] (☛ x 2)

4.4.7 ADF TOP COVER


1. ADF unit (☛ p.4-8)
2. ADF front cover (☛ p.4-10)
3. ADF rear cover (☛ p.4-11)




4. ADF top cover [A] (two tabs, two hooks)

4.4.8 ADF MOTOR


1. ADF unit (☞ p.4-8)
2. Original Tray (☞ p.4-9)
3. ADF feed unit (☞ p.4-9)
4. ADF front cover (☞ p.4-10)
5. ADF rear cover (☞ p.4-11)



6. ADF drive unit [A] (☞ x 4, all ☞s)




7. ADF motor assembly [A] (☞ x 2)




8. ADF motor [A] (☞ x 2)

4.4.9 ORIGINAL SET SENSOR

1. ADF unit (☛ p.4-8)
2. ADF feed unit (☛ p.4-9)
3. ADF motor assembly (☛ p.4-12 "ADF Motor")




4. Feed roller holder [A] (☛ x 1)
5. Upper guide [B] (☛ x 2)



6. Original set sensor [A] (hooks)

4.4.10 ADF COVER OPEN SENSOR

1. Original Tray (● p.4-9)
2. ADF rear cover (● p.4-11)




m018r679

3. ADF cover open sensor [A] (🔑 x 1, 📺 x 1)


4.4.11 ADF FEED SENSOR

1. ADF unit (● p.4-8)
2. ADF feed unit (● p.4-9)



m018r680

3. Sensor cover [A] (🔑 x 2)




m016r681

4. ADF feed sensor [A] (hooks, 📺 x 1)

4.4.12 ADF DRIVE BOARD

1. Original Tray (☛ p.4-9)
2. ADF rear cover (☛ p.4-11)




3. ADF drive board [A] (no screws, all plugs (☛)s and hooks)


4.5 ARDF

4.5.1 ARDF UNIT


1. Left cover (☛ p.4-3)



2. Disconnect the harness [A] (☛ x 1, ☛ x 1) and ground wire [B] (☛ x 1)




3. Open the ARDF unit [A].




4. Release the three hooks of the right hinge [A].
5. Lift the ARDF unit.

4.5.2 ORIGINAL TRAY



m118r204

1. Open the original tray [A] and the ARDF top cover [B].




m118r205

2. Original tray [A] from the left side (Two tabs).

4.5.3 ARDF FEED UNIT


1. Open the ARDF top cover.



2. Release the lock lever [A].
3. ARDF feed unit [B]

4.5.4 ARDF SEPARATION PAD


1. Open the ARDF cover.
2. ARDF feed unit (☛ p.4-18)



3. ARDF separation pad [A] (hook x 2, spring x 1)

4.5.5 ARDF FRONT COVER

1. ARDF unit (☛ p.4-16)
2. Original Tray (☛ p.4-17)
3. ARDF feed unit (☛ p.4-18)




4. At the bottom of the ARDF unit [A] (☛ x 2).




5. ARDF front cover [A].

4.5.6 ARDF REAR COVER


1. ARDF unit (☛ p.4-16)
2. Original Tray (☛ p.4-17)
3. ARDF feed unit (☛ p.4-18)



4. At the bottom of the ARDF unit [A] (☛ x 6).




5. At the bottom of the ARDF unit [A] (☛ x 1).



6. ARDF rear cover [A].

4.5.7 ARDF TOP COVER

1. ARDF unit (p.4-16)
2. ARDF front cover (p.4-19)
3. ARDF rear cover (p.4-20)




4. ARDF top cover [A] from the left side (two tabs, two hooks)


Replacement and Adjustment

4.5.8 ARDF MOTOR

1. ARDF unit (🔧 p.4-16)
2. ARDF front cover (🔧 p.4-19)
3. ARDF rear cover (🔧 p.4-20)




4. ARDF drive unit [A] (🔧 x 4, all 🗨️s)




5. ARDF motor [A] (🔧 x 2)

4.5.9 ARDF COVER OPEN SENSOR

1. ARDF rear cover (☛ p.4-20)
2. ARDF drive unit (☛ p.4-22 "ARDF Motor")




3. Motor plate assembly [A] (☛ x 4, all ☛s)




4. ARDF cover open sensor [A] (☛ x 1)

4.5.10 ORIGINAL SET SENSOR/ORIGINAL REVERSE SENSOR


1. ARDF drive unit (☛ p.4-22 "ARDF Motor")
2. ARDF motor plate assembly (☛ p.4-23)




3. Guide (paper lower) [A] (☛ x 2)




4. Guide (middle add) [A] (☛ x 6)



5. ARDF transport roller [A] (Bush POM x 2, Gear POM x 1).




6. Pushing ground [A] (hook x 3) and the springs.




7. Document eject roller [A] (Ⓒx 1).

Replacement and Adjustment




m118r223

- 8. Guide (middle) [A].



m118r224

- 9. Sensor guide [A].




m118r225

- 10. Original set sensor [A] (🔩 x 1) and original reverse sensor [B] (🔩 x 1)


4.5.11 ARDF FEED SENSOR

1. ARDF drive unit (☛ p.4-22 "ARDF Motor")



m118r218

2. Sensor cover [A] (☛ x 2)




m016r681

3. ARDF feed sensor [A] (hooks, ☛ x 1)

4.5.12 ARDF DRIVE BOARD

1. ARDF drive unit (☛ p.4-22 "ARDF Motor")




m118r219

2. ARDF drive board[A] (☛ x 1, all ☛s and hooks)

4.6 SCANNER UNIT

1. Front cover (☛ p.4-2)
2. Left cover (☛ p.4-3)
3. Rear cover (☛ p.4-5)



m118r114

4. Slide the scanner unit [A] in the direction of the blue arrow, and remove it (⚙️ x 4, ground cable x 2, flat cable x 1, 🗑️ x 3, 🗑️ x 3).
5. ADF unit or ARDF unit (☛ p.4-8 or ☛ p.4-16)
6. Operation Panel (☛ p.4-30)



m016r103

7. Scanner Unit [A]

4.6.1 OPERATION PANEL

1. Scanner unit (☛ p.4-29)
2. ADF unit or ARDF unit (☛ p.4-8 or ☛ p.4-16)



3. Turn the scanner unit over.
4. Operation panel [A] (☛ x 3, hooks)


4.6.2 SCANNER TOP COVER

1. Scanner unit (● p.4-29)
2. Turn the scanner unit over.



m016r104

3. Remove the six screws on the bottom of the scanner base [A].




m016r105

4. Scanner top cover [A] (hooks)


4.6.3 SCANNER CARRIAGE UNIT

1. Scanner unit (☛ p.4-29)
2. Scanner top cover (☛ p.4-31)




m016r106

3. Slide the scanner carriage unit [A] to the right side.




m016r107

4. Loosen the timing belt [A] as shown above, and remove it.




m016r644

5. Remove the flat cable [A] from the scanner carriage unit.



6. Bar holder [A] (🔩 x 1)




7. Carriage bar [A] and scanner carriage unit [B]


Replacement
and
Adjustment

4.6.4 EXPOSURE LAMP

1. Scanner carriage unit (☛ p.4-32)



2. Carriage top cover [A] (☛ x 2, ☛ x 1)



3. Exposure lamp [A] (hooks)


When reinstalling the exposure lamp



Place the lamp cord wires as shown above. Otherwise, the top cover could pinch the lamp cords and damage them when reinstalling the top cover on the scanner carriage unit.


4.6.5 LAMP STABILIZER BOARD

1. Scanner carriage unit (☛ p.4-32)



m018r650

2. Carriage bottom cover [A] (☛ x 2)




m016r651

3. Lamp stabilizer [A] (☛ x 1)

Replacement
and
Adjustment


4.6.6 SCANNER MOTOR

1. Scanner carriage unit (☛ p.4-32)



m018r652

2. Scanner motor [A] (☛ x 3)



m016r653



3. Carriage rail [A] (☛ x 2)
4. Ground plate [B] (double-sided tape)
5. Conductance tape [C]
6. Scanner motor


4.7 LASER UNIT

⚠ CAUTION

- Turn off the main power switch and unplug the machine before attempting any of the procedures in this section. Laser beams can seriously damage your eyes.

4.7.1 CAUTION DECAL LOCATIONS

Caution decal is attached as shown below.



⚠ WARNING

- Be sure to turn off the main switch and disconnect the power plug from the power outlet before beginning any disassembly or adjustment of the laser unit. This machine uses a class IIIB laser beam with a wavelength of 648 to 663 nm and an output of 9 mW. The laser can cause serious eye injury.

Replacement
and
Adjustment

4.7.2 LASER UNIT

- Front cover (p.4-2)
- Left cover (p.4-3)
- Rear cover (p.4-5)
- Scanner unit (p.4-29)
- Top cover (p.4-7)




- Laser unit [A] (screw x 3, ground screw x 3, spacer x 2)

4.7.3 POLYGON MIRROR MOTOR


⚠ CAUTION

- Turn off the main switch and unplug the machine before attempting any of the procedures in this section. Laser beams can seriously damage your eyes.

1. Laser unit (🔧 p.4-37)



2. Polygon mirror cover [A] (🔧 x 2)



3. Polygon mirror motor [A] (🔧 x 4, 📏 x 1)

⬇ Note

- Never touch the surface of the mirror with bare hands.

4.8 PAPER FEED AND EXIT


4.8.1 PAPER FEED ROLLER

1. Pull out the standard paper tray.
2. Remove the AIO.



m016r127

3. Set the machine with the rear side facing down, resting on the table.




m016r128

4. Slide the paper feed shaft [A] to the left side (☞ x 2).
5. Slide the paper feed roller [B] to right side, and remove it (hook).

After installing a new paper feed roller

1. Enter the "Maintenance mode".
2. Select "Engine Maintenance", and then press "OK" key.
3. Select "Reset Paper Feed RoI Life" and then press "OK" key.
4. Press the left key "Execute" of the "Selection keys".
5. Exit the "Maintenance mode".

4.8.2 FRICTION PAD




1. Remove the paper tray unit from the machine before removing the friction pad.
2. Friction pad [A] (2 hooks, 1 spring)

When reinstalling the friction pad follow this order:

1. Replace the spring.
2. Insert the right side of the friction pad first, followed by the left side.
3. Gently push the friction pad down into the slot and then pull forward very slightly.


4.8.3 PAPER END SENSOR



1. Set the machine with the rear side facing down, resting on the table.
2. Paper end sensor [A] (hooks,  x 1)

4.8.4 BY-PASS FEED ROLLER


1. Front cover (☛ p.4-2)
2. Left cover (☛ p.4-3)
3. Right cover (☛ p.4-6)
4. Pull out the paper tray.




5. By-pass lower guide plate [A] (☛ x 4, ☛ x 2)

⚠ Note


- Reinstall the by-pass lower guide plate [A] while pressing the spring [B].
- Be careful for the spring [B] and the ground plate [C] not to fall inside the machine during reinstallation.



Paper Feed and Exit




6. By-pass upper guide plate [A] (hooks)
7. By-pass solenoid cover, by-pass solenoid [B] (⚙️ x 1)
8. Gear [C] (hook)



9. Slide the by-pass feed roller shaft [A] to the left side, and remove it.
10. Remove the metal cover [B] from the by-pass feed roller [C].

4.8.5 BY-PASS FEED ROLLER FRICTION PAD


1. By-pass feed roller (🔧 p.4-41)



2. By-pass feed roller friction pad [A] (hooks, spring x 1)

4.8.6 BY-PASS FEED SENSOR

1. Front cover (☛ p.4-2)
2. Right cover (☛ p.4-5)




m016r152

3. By-pass feed sensor [A] (hooks, ☛ x 1)


4.8.7 PAPER FEED CLUTCH

1. Top cover (☛ p.4-7)
2. Scanner unit (☛ p.4-29)
3. ECB (☛ p.4-62 "ECB (Engine Controller Board)")
4. Controller board (☛ p.4-64)
5. FCU (☛ p.4-64)




m012r109

6. Release all harnesses [A] from the clamps.
7. Harness guide plate [B] (☛ x 2)



m016r704

8. Drive unit [A] (☛ x 5, ☛ x 1, ☛ x 2, timing belt)




m016r113

9. Paper feed clutch [A] (☛ x 1, ☛ x 1)

4.8.8 RELAY CLUTCH


1. Drive unit (☛ p.4-44 "Paper Feed Clutch")



2. Relay clutch [A] (☞ x 1)

4.8.9 REGISTRATION CLUTCH



1. Drive unit (☛ p.4-44 "Paper Feed Clutch")



2. Registration clutch [A] (☞ x 1)

4.8.10 TONER END SENSOR

1. Drive unit (☛ p.4-44 "Paper Feed Clutch")




m016r147

2. Reflective sensor with bracket [A] (☛ x 1)
3. Reflective sensor [B]

4.8.11 PAPER EXIT SENSOR

1. Rear cover (☛ p.4-5)




m016r158

2. Paper exit sensor [A] (☛ x 1, hooks)

4.8.12 RELAY SENSOR


1. Rear cover (☛ p.4-5)



2. Relay sensor [A] (☛ x 1, hooks)

4.8.13 INVERTER SENSOR

1. Duplex transport guide (☛ p.4-65 "PSU")




2. Inverter sensor [A] (☛ x 1, hooks)

Replacement
and
Adjustment

4.8.14 REGISTRATION ROLLER AND SENSOR

1. Pull out the paper tray.
2. PSU (☛ p.4-65)
3. Paper feed clutch (☛ p.4-44)
4. Relay clutch (☛ p.4-45)
5. Registration clutch (☛ p.4-45)




m016r696

6. Heat insulating plate [A] (☛ x 2)
7. Exit roller base [B] (☛ x 2)




m016r694

8. Imaging unit base [A] (☛ x 4)




m016r697

9. Remove the four screws in the right frame [A].



m016r698

10. Remove the four screws in the left frame [A].



m016r699


11. Registration unit [A]
12. Upper guide plate [B]



m016r700

13. Registration roller [A]

Replacement
and
Adjustment




14. Registration sensor [A]

4.9 PAPER TRANSFER

4.9.1 TRANSFER ROLLER

1. Front cover (p.4-2)
2. Remove the AIO.



m016r146

3. Remove the transfer roller [A] (Bushing x 1, spring x 2, gear x 1) as shown above.

Note

- Do not touch the transfer roller surface, when reinstalling the new transfer roller.

After installing a new transfer roller

1. Enter the "Maintenance mode".
2. Select "Engine Maintenance", and then press "OK" key.
3. Select "Reset Transfer Unit" and then press "OK" key.
4. Press the left key "Execute" of the "Selection keys".
5. Exit the "Maintenance mode".


4.10 FUSING

⚠ CAUTION


- Switch off the main power, unplug the machine from its power source, and allow the fusing unit to cool before removing it.

4.10.1 FUSING UNIT


1. Front cover (☛ p.4-2)
2. Left cover (☛ p.4-3)
3. Rear cover (☛ p.4-5)



4. Release the lock [A], and then remove the entrance guide [B] (☛ x 1).



5. Disconnect the three harnesses (☛ x 2)




m016r684

6. Pass the cable [A] through the hole [B] inside the machine.
7. Fusing unit [C] (🔧 x 4)

⬇ **Note**


- Make sure that the two bushings [A] remain be setting.



m016r705

Reinstallation

Pass the cable [A] of fusing unit through the hole [B] outside, after setting the fusing unit.



m016r702

After installing a new fusing unit


1. Enter the "Maintenance mode".
2. Select "Engine Maintenance", and then press "OK" key.
3. Select "Reset Fuser Unit" and then press "OK" key.
4. Press the left key "Execute" of the "Selection keys".
5. Exit the "Maintenance mode".

4.10.2 THERMOSTAT


⚠ CAUTION

- Do not recycle a thermostatic switch that is already opened. Safety is not guaranteed if you do this.

- Fusing unit [A] (🔩 x 3)




- Fusing upper cover [A] (🔩 x 4)




- Thermostat [A] (🔩 x 2)

4.10.3 THERMISTOR

1. Fusing unit (☛ p.4-52)




2. Fusing front cover [A] (☛ x 2)



3. Thermistor [A] (☛ x 1)

4.10.4 FUSING LAMP


1. Fusing unit (☛ p.4-52)



2. Fusing side covers [A] (☛ x 2 each)




3. Ground-wires (🔩 x 1 each)



4. Fusing lamp [A]


When reinstall the fusing lamp




The flat terminal [A] must be placed on the right side of the fusing unit (fusing cable side).

4.10.5 HOT ROLLER

1. Fusing lamp (☛ p.4-56)




2. Brackets [A] (☛ x 2)



3. Hot roller [A] (C-ring x 2, gear x 1, bushing x 2)

4.10.6 PRESSURE ROLLER


1. Hot roller (☛ p.4-58r)




2. Pressure roller [A] (Bearing x 2)

4.10.7 HOT ROLLER STRIPPER PAWLS

1. Fusing unit (☛ p.4-52)
2. Fusing upper cover (☛ p.4-55 "Thermostat")



3. Metal holders [A] (1 holder for each pawl: ☛ x 2 each)




4. Hot roller stripper pawls [A] (1 spring for each pawl)

Replacement and Adjustment

4.11 MOTORS

4.11.1 MAIN MOTOR


1. Front cover (🔩 p.4-2)
2. Left cover (🔩 p.4-3)



3. Main motor [B] (🔩 x 4, 📏 x 1)

4.11.2 DUPLEX MOTOR (FOR M119)


1. Front cover (🔩 p.4-2)
2. Left cover (🔩 p.4-3)
3. Rear cover (🔩 p.4-5)
4. Right cover (🔩 p.4-6)
5. Top cover (🔩 p.4-7)



6. Duplex motor [A] (🔩 x 2, 📏 x 1)

4.12 ELECTRICAL COMPONENTS

4.12.1 LAYOUT OF PC BOARDS




| | |
|-----|---|
| [A] | USB Board |
| [B] | ECB (Engine Controller Board) |
| [C] | Controller Board |
| [D] | FCU (Fax Control Unit) - behind the main controller board |

Replacement
and
Adjustment

USB Host Board


1. Front cover (☛ p.4-2)
2. Left cover (☛ p.4-3)



3. USB host board [A] (☛ x 2, ☛ x 1)

ECB (Engine Controller Board)

1. Front cover (🔧 p.4-2)
2. Left cover (🔧 p.4-3)



3. ECB [A] (🔧 x 4, all 📏s)

Note

- Do not connect any connectors to CN181 when reinstalling the ECB [A]. CN181 is only used for factory.
- Do not change the dip switch. The dip switch is only for factory use.



4. EEPROM (Electrically Erasable Programmable Read Only Memory) [A]

When installing the new ECB (Engine Controller Board)



1. Remove the EEPROM from the old ECB.
2. Install it on the new ECB after replacing the ECB.
3. Replace the EEPROM if the EEPROM on the old ECB is defective.

⚠ CAUTION

- Keep the EEPROM away from any objects that can cause static electricity. Static electricity can damage EEPROM data.
- Make sure that the EEPROM is correctly installed on the ECB.

EEPROM

- Replacement procedures for the new EEPROM are included in the "ECB (Engine Controller Board)" replacement procedure. Refer to "ECB (Engine Controller Board)" for details.
- Do the following settings after installing a "new" EEPROM.
 - Input the PnP Name, Destination in Maintenance mode.
 - Adjust the Registration in Maintenance mode.
 - Input serial number on the serial number input display after installing the new EEPROM

↓ Note


- Ask your supervisor about how to access the serial number input display.

Controller Board

⚠ CAUTION

- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.


1. ECB (🔍 p.4-62 "ECB (Engine Controller Board)")




2. Controller board [A] (🔍 x 4, flat cable x 1, all 📏s)

FCU

1. ECB (🔍 p.4-62 "ECB (Engine Controller Board)")
2. Controller board (🔍 p.4-64)



3. Controller board bracket [A] (🔍 x 6)




4. FCU [A] (🔩 x 4)

4.12.2 PSU

1. Pull out the standard paper tray.
2. Front cover (🔩 p.4-2)
3. Left cover (🔩 p.4-3)
4. Rear cover (🔩 p.4-5)
5. Right cover (🔩 p.4-6)
6. Scanner unit (🔩 p.4-29)
7. Top cover (🔩 p.4-7)
8. ECB (🔩 p.4-62 "ECB (Engine Controller Board)")
9. Controller board bracket (🔩 p.4-64 "FCU")
10. Drive unit (🔩 p.4-44)


Replacement
and
Adjustment



Electrical Components

11. Disconnect three connectors in left frame (🔌 x 1)


12. Bracket [A] (🔧 x 2)




13. Main power switch bracket [A] in right frame (🔧 x 2)

14. Remove the main power cord [B] as shown above (🔌 x 2).

15. Remove the ground wire and two connectors.




16. Rear low cover [A] (🔧 x 3)




17. Release the lock [A], and then remove the entrance guide [B] (🔌 x 1).

18. Fusing Unit (📄 p.4-52)




19. For M119 only: Duplex transport guide [A] (🔩 x 2)




20. For M119 only: Set the machine with the front side facing down, resting on the table.

21. For M119 only: Release the link [A] (🔗 x 1)



22. For M119 only: Duplex cover [A] (🔩 x 4, Ⓢ x 1, gear x 1)




23. PSU [A] (🔩 x 4, 📡 x 1)


Replacement
and
Adjustment

4.12.3 CHARGE TERMINAL CASE

1. Right cover (🔑 p.4-6)



2. Charge terminal case [A] with the harness (🔑 x 2, 📏 x 1, hooks)




3. Remove the harness [A] (🔑 x 4).
4. Remove the four springs and terminal pins [B].
5. Charge terminal case [C]

4.13 OTHERS

4.13.1 COOLING FAN

1. Right cover (☛ p.4-6)




2. Cooling fan [A] (☛ x 2, ☛ x 1)

⚠ CAUTION

- Install the Cooling fan [A] with its decal facing the outside of the machine.

4.13.2 SPEAKER


1. Left cover (☛ p.4-3)



2. Speaker [A] (☛ x 2, ☛ x 1, ☛ x 1)

4.13.3 QUENCHING LAMP

1. Top Cover (☛ p.4-7)



2. Release two hooks of the quenching lamp with the case [A], and remove it.



3. Remove the quenching lamp [A] from the case (hook x 3).

4.14 IMAGE ADJUSTMENT


4.14.1 REGISTRATION ADJUSTMENT

User Adjustment

The paper registration can also be adjusted with the user mode ("User Tools"). For details, see the "User Guide".

Service Adjustment

1. Print the test page (☛ p.6-9).
 - Print out the test pattern before changing the paper registration setting.
2. Enter the "Maintenance mode".
3. Select "Engine Maintenance", and then press "OK" key.
4. Select the "Registration", and then press "OK" key.



m016t500

- (1): Feed Direction
 - (2): Vertical Adjustment
 - (3): Horizontal Adjustment
 - (4): Print Area
5. Press the "Up" or "Down" keys to set the registration value from -15 to +15 (that is, from -1.5 to +1.5 mm, in 0.1 mm increments).
 - Increase the value to shift the print area in the plus direction.
 - Decrease to shift in the minus direction.
 6. Adjust the margins of the test page so that they are equal in size.

SYSTEM MAINTENANCE REFERENCE

| REVISION HISTORY | | |
|------------------|------|-------------------|
| Page | Date | Added/Updated/New |
| | | None |

5. SYSTEM MAINTENANCE REFERENCE

5.1.1 OVERVIEW

This model has several service menus. Each service menu has several adjustment items. This section explains how to enter each service menu and what you can do in each service menu.

5.1.2 MAINTENANCE MODE MENU

To access Maintenance Mode do the following:

- Type the following keys, in sequence: [Clear/Stop] > [1] > [0] > [7]
- Hold down the [Start Key] until the Maintenance Mode screen is displayed.

Note: This should take about 3 seconds.

Selecting an Item

To select an item, press the "Up" or "Down" key.

Going into the Next Level/ Returning to the Previous Level

- To go into the next level of an item, select an item then press the "OK" key.
- To return to the previous level of an item, press the "Return" key.

Exiting the Maintenance Mode Menu

To exit the maintenance mode menu, press the "Clear/Stop" or "Return" key until the "Ready" display appears.

Menu List

| Display Info | | |
|---------------------|-------------------|--|
| Model Name | | Displays the Model Name, Depends on Engine Firmware Settings |
| FW Ver. | CTL FW Version | Displays the Firmware Version |
| | FAX FW Version | Displays the FAX Firmware Version. |
| | Engine FW Version | Displays the Engine Firmware Version |
| Counter | Printer Counter | Displays the following counters of the printer engine. Black image (Total Page) |
| | Scanner Counter | Displays the sum total of scanner counters for each mode. Total Page/ Color Image/ Black Image/ ADF Used |
| | Jam Counter | Displays the number of paper jams at each location. Jam to Total/ ADF/ Printer Out Bin/ Internal/ Tray1/ Duplex |

| Print Reports | |
|-----------------------|--|
| G3 Protocol dump list | G3 protocol dump of the latest communication is printed. Off (Default)/ Error/ On |

| Engine Maintenance | |
|--------------------|---|
| PnP Name | Sets the model name to a host via USB device. Do not change this setting (Designed for Factory Use). [0x00 – 0x7F] |
| Destination | Sets the destination and updates the engine setting. Do not change this setting (Designed for Factory Use). DOM/ NA/ EU (Default)/ ASIA/ CHN/ TAIWAN/ KOREA |
| Registration | Horiz. Tray1 Adjusts the horizontal registration for tray 1. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Tray1 Plain Adjusts the vertical registration of plain paper for tray1. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Tray1 Thick Adjusts the vertical registration of thick paper for tray 1. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Tray1 Thin Adjusts the vertical registration of thin paper for tray 1. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |

| Engine Maintenance | | |
|--------------------|-------------------|---|
| Registration | Horiz. Tray2 | Adjusts the horizontal registration for tray 1. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Tray2 Plain | Adjusts the vertical registration of plain paper for tray 2. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Tray2 Thick | Adjusts the vertical registration of thick paper for tray 2. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Tray2 Thin | Adjusts the vertical registration of thin paper for tray 2. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| Registration | Horiz Bypass tray | Adjusts the horizontal registration for the bypass tray. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert Bypass Plain | Adjusts the vertical registration of plain paper for the bypass tray. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert Bypass Thick | Adjusts the vertical registration of thick paper for the bypass tray. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |

| Engine Maintenance | | |
|---------------------|---|--|
| | Vert Bypass Thin | Adjusts the vertical registration of thin paper for t the bypass tray. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| Registration | Horiz. Dup. Back | Adjusts the horizontal registration the back side in duplex mode. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Dup Back Plain | Adjusts the vertical registration of plain paper for the back side in duplex mode. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Dup Back Thick | Adjusts the vertical registration of thick paper for the back side in duplex mode. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| | Vert. Dup Back Thin | Adjusts the vertical registration of thin paper for the back side in duplex mode. If the machine settings are reset to the factory defaults, this value does not change. [-40 to 40 / 0 (Default) / 0.1 mm/step] |
| Brand ID | 00* – 7F Displays the current brand ID number. Do not change this setting (Designed for Factory Use). | |
| Fuser SC Reset | This button is for resetting an SC related with the fusing errors. | |
| Reset Transfer Unit | Clears the EM counter of the transfer roller. | |

| Engine Maintenance | | |
|---------------------------|---|--|
| Reset Paper Feed Rol Life | Clears the EM counter of the paper feed roller. | |
| Reset Fusing Unit | Clears the EM counter of the fusing unit. | |
| Motor Rotation Time | Displays the main motor rotation time. | |
| Prt Cartridge Info | Kind ID | Displays the toner cartridge (AIO) information (Kind ID). |
| | Toner End History | Displays the toner cartridge (AIO) information (Toner End History). |
| | Refill Flag Status | Displays the toner cartridge (AIO) information (Refill flag status). |
| | Unit Print Counter | Displays the toner cartridge (AIO) information (Unit Print Counter). |
| OPC Life Info | OPC Rotation Time | Displays the OPC life information (OPC rotation time). |
| | Pre-OPC Rotation Time | Displays the OPC life information (Pre-OPC rotation time) |
| | OPC Alert Status | Displays the OPC life information (Alert status) |
| | OPC Pre-Alert Status | Displays the OPC life information (Pre-Alert status) |

| Engine Maintenance | | |
|---------------------|---|---|
| EM Counter Info | Transfer Roller Remain | Displays the total counter (Remain of Transfer Roller). |
| | Transfer Roller - Time | Displays the EM counter (Transfer Roller: Time). |
| | Transfer Roller - Pages | Displays the EM counter (Transfer Roller: pages). |
| | Paper Feed Roller Remain | Displays the total counter (Remain of Paper Feed Roller). |
| | Paper Feed Roller - Pages | Displays the EM counter (Paper Feed Roller: pages). |
| | Fusing Unit Remain | Displays the total counter (Remain of Fusing Unit). |
| | Fusing Unit - Time | Displays the EM counter (Fusing Unit: time). |
| | Fusing Unit - Pages | Displays the EM counter (Fusing Unit: pages). |
| Total Counter Info | Engine Counter | Displays the total counter (Engine). |
| Clear Engine Memory | Resets the engine settings stored in the EEPROM to factory default. | |
| SC559 Detection | [On or Off (Default)] | |
| EM Life Display | Sets the display of alert when each EM parts yield of this machine is reached. [On or Off (Default)] | |

| Engine Maintenance | | |
|---------------------|--------------------------|---|
| Output check | Main Motor | Output check (Main Motor) |
| | Middle Clutch | Output check (Relay Clutch) |
| | Tray1 Clutch | Output check (Paper Feed Clutch) |
| | Bypass solenoid | Output check (Bypass solenoid) |
| | Regist Clutch | Output check (Registration Clutch) |
| | Reserve Clutch | Output check (Reserve Clutch) |
| | Fan High Speed | Output check (Fan High Speed) |
| | Fan Low Speed | Output check (Fan Low Speed) |
| | Erase Lamp | Output check (Quenching Lamp) |
| | Polygon Motor | Output check (Polygon Motor) |
| | Tray2 Motor | Output check (Tray2 Motor) |
| | Dup Motor Normal | Output check (Duplex Motor Normal) |
| | Dup Motor Reserve | Output check (Duplex Motor Reverse) |
| Paper Buckle Amount | Vert. Tray1 Plain Paper | Adjusts the amount of paper buckle at the registration roller for each tray and paper type. [-8 to 8 / 0 (Default) / 1 mm/step] |
| | Vert. Tray1 Thick Paper | |
| | Vert. Tray1 Thin Paper | Adjusts the amount of paper buckle at the registration roller for each tray and paper type. [-8 to 8 / -2 (Default) / 1 mm/step] |
| | Vert. Bypass Plain Paper | Adjusts the amount of paper buckle at the registration roller for each tray and paper type. [-8 to 8 / 0 (Default) / 1 mm/step] |
| | Vert. Bypass Thick Paper | |
| | Vert. Bypass Thin Paper | |

| Engine Maintenance | | |
|-------------------------|-------------------------|--|
| | Vert. Tray2 Plain Paper | Adjusts the amount of paper buckle at the registration roller for each tray and paper type. [-8 to 8 / 0 (Default) / 1 mm/step] |
| | Vert. Tray2 Thin Paper | |
| | Vert. Tray2 Thick Paper | |
| | Vert. Dup. Plain Paper | Adjusts the amount of paper buckle at the registration roller for each tray and paper type. [-8 to 8 / 0 (Default) / 1 mm/step] |
| | Vert.Dup. Thin Paper | |
| | Vert Dup. Thick Paper | |
| Fusing Unit Temperature | Plain Paper | Adjusts the fusing temperature for plain paper. [150 to 190 / 175 (Default) / 5°C/step] |
| | Thick1 Paper | Adjusts the fusing temperature for thick 1 paper. [160 to 200 / 185 (Default) / 5°C /step] |
| | Thick2 Paper | Adjusts the fusing temperature for thick 2 paper. [160 to 200 / 185 (Default) / 5°C/step] |
| | Standby | Adjusts the fusing temperature in the standby mode. [120 to 175 / 155 (Default) / 1°C/step] |
| | Low Power | Adjusts the fusing temperature in the low power mode. [80 to 135 / 120 (Default) / 5°C/step] |

| Engine Maintenance | | |
|-------------------------|--|---|
| Fusing Unit Temperature | Thin Paper | Adjusts the fusing temperature for thin paper. [140 to 165 / 150 (Default) / 5°C/step] |
| | Envelope | Adjusts the fusing temperature for envelope. [170 to 200 / 200 (Default) / 5°C/step] |
| | Postcard | Adjusts the fusing temperature for postcard. [160 to 200 / 185 (Default) / 5°C/step] |
| | Recycled | Adjusts the fusing temperature for recycled paper. [150 to 180 / 160 (Default) / 5°C/step] |
| Charge Bias | Adjusts the charge bias. [1050 to 1300 / 1200 / 25 /step] | |
| Developer Bias | Adjusts the developer bias. [270 to 330 / 300 / 15 /step] | |
| Trans. Roller Bias | Adjusts the transfer roller bias. [-6 to 6 / 0 / 1 /step] | |
| Subscan Magnification | Adjusts the sub scan magnification. [-8 to 8 / 0 / 1 /step] | |
| Toner Near End To End | Sheets | Adjusts the printable sheets between "toner near end" to "toner end". [0 to 255 / 200 / 1 sheet/step] |
| | Dot Count | Adjusts the printable dot count between "toner near end" to "toner end". [0 to 255 / 100 / 1 dot/step] |

| Engine Maintenance | | |
|----------------------|--|--|
| Waste toner disposal | Independent-Supply Toner | <p>Sets the machine operation at "waste toner full" of the refilled AIO.</p> <p>[On or Off (Default)]</p> <p>Note</p> <ul style="list-style-type: none"> With main motor rotation count feature, machine can be set to stop printing after print total exceeds a certain set value. If print count exceeds this value, then "Replace Print Cartridge" remains in display. Then a new AIO cartridge must be installed. This feature is a safety measure to prevent the used toner tank from becoming full (there is no toner overflow detection mechanism). |
| Test Pattern | Prints the test pattern. | |
| Curl Control Mode | <p>Corrects the face curl of paper.</p> <p>0: OFF (28ppm)</p> <p>1: Sets the engine speed at 14ppm after printing 1 minute.</p> <p>2: Sets the engine speed at 14ppm.</p> <p>3 to 255: not available</p> <p>[0 to 255 / 0 / 1 /step]</p> | |
| Adjust Charge Bias | <p>Charge bias correction for dirty background</p> <p>0: OFF (Default)</p> <p>1: ON</p> <p>2 to 255: not available</p> <p>[0 to 255 / 0 / 1 /step]</p> | |
| 1200dpi LD Power | <p>Adjusts print density (density levels by increasing the number)</p> <p>[31 to 155 / 112 (Default) / 1 /step]</p> | |

| Scan Maintenance | | |
|---------------------|---|--|
| Mono Compression | Sets the monochrome compression type for scanning. MH (Default)/ MR/ MMR | |
| Registration Adjust | ADF Main Reg. | Adjusts the ADF Scan main-scan registration. [-2.0 to 2.0 / 0 (Default)/ 0.1 %/step] |
| | ADF Sub Reg. | Adjusts the ADF Scan sub-scan registration. [-2.0 to 2.0 / 0 (Default)/ 0.1 %/step] |
| | Flatbed Main Reg. | Adjusts the Flatbed Scan main-scan registration. [-2.0 to 2.0 / 0 (Default)/ 0.1 %/step] |
| | Flatbed Sub Reg. | Adjusts the Flatbed Scan sub-scan registration. [-2.0 to 2.0 / 0 (Default)/ 0.1 %/step] |
| Size Adjust | ADF Main Reg. | Adjusts the ADF Scan main-scan magnification. [-0.9 to 0.9 / 0 (Default)/ 0.1 %/step] |
| | ADF Sub Reg. | Adjusts the ADF Scan sub-scan magnification. [-0.9 to 0.9 / 0 (Default)/ 0.1 %/step] |
| | Flatbed Main Reg. | Adjusts the Flatbed Scan main-scan magnification. [-0.9 to 0.9 / 0 (Default)/ 0.1 %/step] |
| | Flatbed Sub Reg. | Adjusts the Flatbed Scan sub-scan magnification. [-0.9 to 0.9 / 0 (Default)/ 0.1 %/step] |

| Fax Maintenance | | |
|-----------------|----------|--|
| Modem Settings | RX Level | Sets the reception level. [-43 dBm (Default)/ -33 dBm/ -26 dBm / -16 dBm] |
| | TX Level | Sets the transmission level. [-1 dBm to -15 dBm/ -15dBm (Default)/ 1 dBm/ step] |

| Fax Maintenance | | |
|------------------------------|------------------------|---|
| | Cable Equalizer | These selectors are used to improve the pass-band characteristics of analogue signals on the telephone line. [0Km (Default)/ 1.8Km/ 3.6Km/ 7.2Km] |
| Protocol Definition | Training Retries | This sets the number of training retries to be repeated before automatic fallback. [1 Time/ 2 Times (Default)/ 3 Times/ 4 Times] |
| | Encoding | Sets the compression method for Tx/Rx. [MMR+MR+MH (Default)/ MR+MH/ MH] |
| Protocol Definition Timer | T0 Timer | Timeout for response from the called station in automatic sending mode [35 Sec/ 45 Sec/ 55 Sec / 60 Sec (Default)/ 90 Sec/ 140 Sec] |
| | T1 Timer | Set the time length for the T1 timer. [40 Sec (Default)/ 50 Sec] |
| | T4 Timer | Set the time length for the T4 timer. [3 Sec (Default/ 4.5 Sec] |
| RX Settings | Silence Detection Time | Silence (No tone) detection time (Rx mode : FAX/ TAD Only) After the line is connected via the external telephone, the machine can detect silence (no tone) for the time length specified by this setting. [30 sec (Default)] |
| | CNG Tone Detection | CNG tone detection time (RX mode : FAX / TEL, FAX / TAD Only) After the line is connected via the external telephone, the machine can detect a CNG signal for the time length specified by this setting. [5 Sec (Default)/ 10 Sec] |

| Fax Maintenance | | |
|-----------------------------|-----------------------|---|
| | CNG Cycles | Number of CNG cycles to be detected This setting is only effective for FAX/TAD mode. [1.5 Cycle (Default)/ 2.0 Cycle] |
| RX Settings | Tone Sound Monitoring | Determines the period when tones from the line are monitored. [No Monitoring/ Up To Phase B (Default)/ All TX Phases] |
| | Stop/Clear Key | Pressing the Stop/Clear key can stop the current receiving operation. Received data is lost. [No Functional (Default)/ Functional] |
| | Off-Hook Level | Sets the off-hook detection threshold. [10V (Default)/ 15V/ 20V/ 25V] |
| | Off-Hook Detection | Sets the Off-Hook detection period. 200 msec (Default)/ 800 msec |
| TX Settings | Redial Interval | Sets the redial interval when Tx fails. [5 Min (Default)/ 6 Min] |
| | Redialings | Sets the number of redials when Tx fails. [2 times/ 3 Times (Default)/ 4 Times/ 5 Times] |
| Overseas Comm Mode Settings | Overseas Comm Mode | This sets the machine to ignore a DIS signal sent from the called station once in a sending operation. [Off (Default)/ Ignore DIS Once] |
| | Minimum Time Length | If this setting is set to "On", the machine detects the CNG signal after the line is connected. If it is set to "Off", the machine detects the CNG signal as long as the line is connected. [100 Ms/ 200 Ms/ 300 Ms/ 400 Ms (Default)] |

| Fax Maintenance | | |
|----------------------|----------------------------|---|
| Dial Pulse Setting | Dial Pulse Type | <p>This sets the number of pulses that are generated during dialing.</p> <ul style="list-style-type: none"> ▪ N: Dialing '0' generates 10 pulses --- Dialing '9' generates 9 pulses. (Default) ▪ N+1: Dialing '0' generates 1 pulses --- Dialing '9' generates 10 pulses. ▪ 10-N: Dialing '0' generates 10 pulses --- Dialing '9' generates 1 pulse. |
| Tone Signal Settings | Tone Signal Transmission T | Sets the tone signal transmission time length [100 ms (Default)] |
| | Minimum Pause In Tone Dial | Sets the minimum pause during tone dialing [100 ms (Default)/ 150 ms/ 200 ms] |
| | Attenuator of Pseudo Ring | Sets the attenuator for pseudo ringback tone to the line [0 to 15 / 10 (Default)/ 1 dB/step] |
| | DTMF Level | Sets the transmission level of DTMF tones. [-12 dBu / -11 dBu/ -10 dBu (Default)/ -8 dBu/ -6 dBu] |
| | DTMF Delta | Sets the level difference between high band frequency signals and low band frequency signals when sending DTMF tones. [2 dBu/ 3 dBu] |
| 1Dial Tone Detection | Wait Time | The machine starts dialing after the specified interval without detection of a dial tone when Dial tone detection is set to "No detection". [3.5 Sec (Default)/ 7.0 Sec/ 10.5 Sec / 14.0 Sec] |

| Fax Maintenance | | |
|--------------------------|----------------|--|
| | Timeout Length | This setting sets the time-out length for the 1st dial tone detection. The machine waits for a dial tone for the specified time and disconnects itself from the line when no dial tone is input. [10 Sec (Default)/ 15 Sec/ 20 Sec/ 30 Sec] |
| BT (Busy Tone) Detection | BT Setting | DFU [Off/ On] BT: Busy tone |
| | BT Frequency | DFU [300-550 Hz/ 300-650 Hz/ 325-525 Hz/ 340-550 Hz/ 350-500 Hz/ 350-550 Hz/ 375-475 Hz/ 380-520 Hz] |
| | BT Level | DFU [-35 dB/ -36 dB/ -37 dB/ -38 dB/ -39 dB] |
| | BT Cadence | DFU [0.10/ 0.15/ 0.20/ 0.25/ 0.30/ 0.35/ 0.40/ 0.45/ 0.50/ 0.75] |
| Comm Settings | RTN Rate | The machine checks the actual data reconstruction errors and then transmits an RTN depending on the decoding error rate that is set by this setting (Number of lines containing an error per page / Total number of lines per page). [10%/ 15%] |
| | V34 Modem | DFU [Permitted (Default)/ Prohibited] |
| | V17 Modem | DFU [Permitted (Default)/ Prohibited] |

| Fax Maintenance | | |
|-----------------------|--------------------------|--|
| V34 Settings | Equalizer | These selectors set the equalizer's training level to be applied if training fails due to poor line connection. [Automatic (Default)/ 4 Points/ 16 Points] |
| | Redialing | Resend when a communication error occurs. [Disabled (Default)/ Not Disabled] |
| | First TX Speed | Sets the first transmission speed choice, before fallback. [2400 Bps/ 4800 Bps/ 7200 Bps/ 9600 Bps/ 12000 Bps/ 14400 Bps/ 16800 Bps/ 19200 Bps/ 21600 Bps/ 24000 Bps/ 26400 Bps/ 28800 Bps/ 31200 Bps/ 33600 Bps (Default)] |
| | Symbol Rate | This setting limits the transmission speed range in V.34 mode by masking the desired symbol rate(s). [Not Used (Default)/ 3429 Sym/Sec / 3200 Sym/Sec/ 3000 Sym/Sec / 2800 Sym/Sec/ 2400 Sym/Sec] |
| Internet Fax Settings | Internet Fax Function | Sets the internet fax function (simple mode of ITU-T.37). Disable/ Enable (Default) |
| | Reply-To Settings | Sets Reply-To settings in SMTP-AUTH. If sets "Yes", the "Mail Address (Machine)" is set in the "Reply-To" field, and the set up information of the "Administrator E-mail Address" is set in the "From" field. No (Default)/ Yes |
| | Prt Rec. Txt Mail Header | This setting determines whether the header information is printed with text e-mails when they are received. No (Default)/ Yes |

| Factory Default | | |
|-----------------|---------|--|
| Factory Default | Return | Does not execute anything. Returns to an upper level. |
| | Execute | <p>Resets all the settings to factory default.</p> <p>Note</p> <ul style="list-style-type: none"> Clears/ resets the contents of the controller board memory (all data programmed by the user, log data) to factory default. <p>After executing, initial setup menu starts after power-on.</p> |

| CTL Maintenance | |
|-----------------|---|
| PDL Mode | <p>ON = "PDL Settings" is shown (Default)</p> <p>OFF = "PDL Settings" is hidden</p> |
| FW Update Mode | <p>If updating the machine that the LDAP authentication is set, execute this mode.</p> <p>[Execute/ Return]</p> <p>After pressing "Execute", the display shows "Please Restart Machine...." Turn the machine's main power off, and then on. Then the machine activates as a special boot loader mode. After that update the firmware via USB cable.</p> |

5.1.3 FAX SERVICE TEST MENU

Entering the Fax Service Test Menu

Turn on the machine while pressing the "Fax" key.

Selecting an Item

To select the item, press the "Up" or "Down" key.

Going into the Next Level/ Returning to the Previous Level

- To go into the next level of an item, select an item then press the "OK" key.
- To return to the previous level of an item, press the "Escape" key.

Exiting the Maintenance Mode Menu

To exit the maintenance mode menu, press the "Clear/Stop" or "Escape" key until the "Ready" display appears.

Menu List

| Fax Test | | |
|----------------|-----------------|---------------------------------------|
| Off-Hook Test | On Hook | Executes the on hook test. |
| | Off Hook | Executes the off hook test |
| CED Test | | Executes the CED test. |
| CNG Test | 1100 Hz | Executes the CNG test |
| ANSam Test | | Executes the ANSam test. |
| Ring Tone Test | | Executes the ring tone test. |
| DTMF Test | Tone [0] to [9] | Executes the DTMF tone 0 to 9 test. |
| | Tone [*] | Executes the DTMF tone * test. |
| | Tone [#] | Executes the DTMF tone # test. |
| | Tone Stop | Executes the Stop DTMF tone test. |
| Modem Test | [V34] 33600 Bps | Generates the [V34] 33600 bps signal. |
| | [V34] 28800 Bps | Generates the [V34] 28800 bps signal. |

| Fax Test | | |
|----------|-----------------|---------------------------------------|
| | [V17] 14400 Bps | Generates the [V17] 14400 bps signal. |
| | [V17] 12000 Bps | Generates the [V17] 12000 bps signal. |
| | [V17] 9600 Bps | Generates the [V17] 9600 bps signal. |
| | [V17] 7200 Bps | Generates the [V17] 7200 bps signal. |
| | [V29] 9600 Bps | Generates the [V29] 9600 bps signal. |
| | [V29] 7200 Bps | Generates the [V29] 7200 bps signal. |
| | [V27] 4800 Bps | Generates the [V27] 4800 bps signal. |
| | [V27] 2400 Bps | Generates the [V27] 2400 bps signal. |
| | [V21] 300 Bps | Generates the [V21] 300 bps signal. |
| | Signal Stop | Generates the Stop signal. |


5.2 CONFIGURATION AND MAINTENANCE PAGE

5.2.1 OVERVIEW

The configuration page and maintenance page have information about the machine's status. Print this sheet as shown below. Check the configuration page or maintenance page when doing machine maintenance.

To Print the Configuration Page/ Maintenance Page

1. Turn on the machine.



m118s001

2. Press the "User Tools" key.
3. Press the "Up" or "Down" key to select "Print List/Report", and then press the "OK" key.
4. Press the "Up" or "Down" key to select "Configuration Page" or "Maintenance Page", and then press the "OK" key.
5. The configuration page or maintenance page is printed.

Other Types of Reports

You can also check other reports than two reports (configuration page and maintenance page) with "Print List/Report" in the "User Tools".

- Fax Journal
Prints a fax transmission and reception report for the last 150 jobs.
- TX/RX Standby File List
Prints a list of unsent fax jobs remaining in the machine's memory.
- Quick Dial Dest. List
Prints a list of scan and fax Quick Dial entries.
- Fax Speed Dial Dest. List
Prints a list of Speed Dial entries.
 - No Sort
Prints the list with the entries sorted by Speed Dial registration number.
 - Sort By Name
Prints the list with the entries sorted by name.
- Scanner Dest. List
Prints a list of scan destinations.
- Scanner Journal
Prints a scan transmission report.
- Special Sender List
Prints a list of authorized RX sender.

Total Counter

Total Counter:

The total counter incremented by the "**engine controller board**" each time the board issues a print command to the engine.

The value is calculated as follows:

Total counter = Copier counter + Printer counter + FAX counter + Reports print

Application Counters:

Application counters exist for each individual primary machine function (Copier, Printer, FAX, etc.), and are incremented by the "**controller board**" each time the board issues a print request for the function in question.

5.3 FIRMWARE UPDATING

★ Important

- Never turn the machine's main power off while the firmware is being updated, as this could damage the ECB or controller board.

5.3.1 CHECKING THE MACHINE FIRMWARE VERSION

To update the firmware for this machine, you need the most recent version of the firmware (firmware file downloadable from the Internet).

1. Turn on the machine.
2. Press the "User Tools" key.
3. Press the "Up" or "Down" key to select "Print List/Report", and then press the "OK" key.
4. Press the "Up" or "Down" key to select "Configuration Page" or "Maintenance Page", and then press the "OK" key.
5. Check the "Firmware Version" (Controller) and "Engine FW version" on the list of the pages.

5.3.2 UPDATING THE CONTROLLER FIRMWARE

Using the following procedure to update the controller firmware, be sure to print the configuration page both before and after the update. Comparing pre- and post-update configuration pages allows you to check whether or not the update was successful.

Follow the procedure carefully, and note that it will vary in parts depending on which version of the firmware is currently installed.

Procedure


When updating firmware, always disconnect any other cable(s) than the one being used for the update operation.

(When updating firmware via USB cable, first disconnect any network and phone line cables, and when updating firmware via LAN cable, first disconnect any USB and phone line cables.)

1. Prepare:
 - Computer: Windows XP/Vista/7, Windows Server 2003/2003 R2, 2008/2008 R2
 - USB cable or LAN (Local Area Network) cable
2. Download the firmware files to your computer.
 - FwUpdateToolSP.exe (Service Mode execute file)
 - Setting.ini (Parameter setting)
 - xxx.brn (Controller Firmware)
3. Make a folder on a local drive of your computer and save the files there.
4. Connect a computer and the machine through a network or directly by USB.

Firmware Updating

5. Click the "FWUpdateToolSP.exe" file to execute the updating program.



6. For a USB connection, click "F/W Update (USB)" [A]. For a network connection, enter the machine's IP address in "Machine IP" [B], and then click "F/W Update (NET)" [C].
7. Check the firmware update tool window for messages and the update's current percentage of completion.

⚠ CAUTION

- Do not turn off the main power from this point until the update procedure is completed.
8. Wait until "FW Update Done.***Please reboot the Machine.***" appears in the firmware update tool window. Also check that update completion message appears on the machine's control panel.
 9. Turn off the power of the machine, and then turn it back on.
 10. Print a configuration or maintenance page to check the machine's firmware version.


5.3.3 UPDATING THE ENGINE FIRMWARE

Procedure

When updating firmware, always disconnect any other cable(s) than the one being used for the update operation.

(When updating firmware via USB cable, first disconnect any network and phone line cables, and when updating firmware via LAN cable, first disconnect any USB and phone line cables.)

1. Prepare:
 - Computer: Windows XP/Vista/7, Windows Server 2003/2003 R2, 2008/2008 R2
 - USB cable or LAN (Local Area Network) cable
2. Download the firmware files to your computer.
 - FwUpdateToolSP.exe (Service Mode execute file)
 - Setting.ini (Parameter setting)
 - yyy.bin (Engine Firmware)
3. Make a folder on a local drive of your computer and save the files there.
4. Connect a computer and the machine through a network or directly by USB.
5. Click the "FWUpdateToolSP.exe" file to execute the updating program.



6. For a USB connection, click "Eng. F/W Update (USB)" [A]. For a network connection, enter the machine's IP address in "Machine IP" [B], and then click "Eng. F/W Update (NET)" [C].
7. Check the firmware update tool window for messages and the update's current percentage of completion.

Note

- You will see the progress percentage appear while the update is in progress.
 - Do NOT turn the main power of the machine off during updating.
8. Wait until “FW Update Done.***Please reboot the Machine.***” appears in the firmware update tool window. Also check that update completion message appears on the machine's control panel.
 9. Turn off the power of the machine, and then turn it back on.
 10. Print a configuration or maintenance page to check the machine's firmware version.

5.3.4 UPDATING THE BOOT LOADER FIRMWARE

This is also listed on the configuration page, but this firmware is not updated in the field.

5.3.5 UPDATING FAILURE

If the firmware update is not successful, the update process is suspended and an error message should display on the FW Update Tool screen. If this happens, DO NOT turn off the machine, and execute the update procedure again (unless the error message "Downloaded file is broken! Do NOT use print, scan, fax and copy function at the same time." is displayed).

If power is turned off accidentally during a firmware update, the firmware will not be correctly updated, and the machine may not start up normally. If the machine does not start up normally, the controller firmware and/or the engine firmware will need to be updated again.

When the machine does not start up normally, in most cases, the panel display will indicate one of the following two conditions:

- When attempting to restart the machine, the LCD panel display indicates "Initializing" indefinitely.
In this case, the controller firmware update has failed. The controller firmware must be updated again.
- When attempting to restart the machine, the LCD panel display indicates "Please Download Engine FW Again!"
In this case, the engine firmware update has failed. The engine firmware must be updated again.

5.3.6 FW UPDATE TOOL MESSAGES

FW Update Tool Messages: Information

Message for USB update

| Messages | Comment | Action |
|---|--|---|
| USB Upload : End of data | Send F/W file to MFP successfully. (Transmission Time: <30 sec) | Please reboot MFP after panel shows reboot message. |
| USB Upload : FAIL | Can not open USB printer driver while F/W file is transmitted. | Check USB cable connection. Check the installation of USB Print Driver if it is available. Check MFP status if it is available. |
| | F/W file transmission can not be completed. (Transmission will be canceled if timeout.) | Check USB cable connection. Check USB Print Driver if it is available. Check MFP status if it is available. |
| Can't open ROM file.Please check ROM file. | F/W file does not exist. | Check the download file name in setting.ini. "ImageFile=" |
| Can't open Eng. ROM file. Please check Eng. ROM file. | Engine F/W file does not exist. | Check the download file name in setting.ini. "EngImageFile=" |
| | | Check the download file and fw update tool is in the same folder. |
| | | Check the download file and fw update tool is in the same folder. |

Firmware Updating

| Messages | Comment | Action |
|--|---------------------------|----------------------------|
| New Version: Update FW | AIO FW is transmitting | Not available |
| Eng FW version: Update Eng FW | Engine FW is transmitting | Not available |
| Firmware is Updating... | AIO FW is updating | Not available |
| Eng Firmware is Updating... | Engine FW is updating | Not available |
| FW Update Done. *** Please reboot the Machine.*** | F/W update is completed. | Please reboot the Machine. |

Message for Network update

| Messages | Comment | Action |
|--------------------------|---|---|
| Connecting... | Connect to MFP. | Please wait a moment. |
| Net Upload : End of data | Update F/W successfully. (Transmission Time: <30 sec) | Please reboot MFP after panel shows reboot message. |
| Net Upload : FAIL | Can not open FTP port of MFP before F/W file is transmitted. (Transmission will be canceled if timeout.) | (1) Check network cable connection. (2) Check MFP status if it is available. (3) Check MFP and PC IP address setting. (4) Check PC firewall setting about FTP. |
| | F/W file transmission can not be completed. (Transmission will be canceled if timeout.) | (1) Check network cable connection. (2) Check MFP status if it is available. |

| Messages | Comment | Action |
|--|---------------------------------|---|
| Can't open ROM file. Please check ROM file. | F/W file does not exist. | Check the download file name in setting.ini. "ImageFile=" |
| Can't open Eng. ROM file. Please check Eng. ROM file. | Engine F/W file does not exist. | Check the download file name in setting.ini. "EngImageFile=" |
| New Version: Update FW | AIO FW is transmitting | Not available |
| Eng FW version: Update Eng FW | Engine FW is transmitting | Not available |
| Firmware is Updating... | AIO FW is updating | Not available |
| Eng Firmware is Updating... | Engine FW is updating | Not available |
| FW Update Done. *** Please reboot the Machine.*** | F/W update is completed. | Please reboot the Machine. |

FW Update Tool Messages: Error**Message for USB update**

| Messages | Comment | Action |
|---|--|---|
| Machine is not ready. | Can not get MFP status form USB status channel before F/W file is transmitted. | Check USB cable connection. Check USB Print Driver if it is available. Do not update F/W when MFP is in power-on stage. |
| Wrong Model. | F/W file is not matched for current machine. | Please check the version of F/W file and machine if it is suitable for MFP. |
| Machine is busy. | F/W update is running. Other MFP functions are running. | Please wait F/W update is completed. Please wait other MFP functions are completed. |
| FW Update Done. *** Please reboot the Machine.*** | F/W update is completed. | Please reboot the Machine. |
| Machine loses communication. ***Please check FW Update Done. Then reboot the Machine.*** | F/W file has transmitted. Polling F/W update progress fail. | Do not reboot engine till Engine Panel display "Firmware Update Done. Please reboot". Then reboot engine. |
| Downloaded file is broken! Do NOT use print, scan, fax and copy function at the same time. | F/W checks the downloaded file. And get wrong checksum. So stop to modify F/W. | Check the downloaded file is not broken. Do not use MFP functions when update firmware. |

Message for Network update

| Messages | Comment | Action |
|---|--|---|
| Machine is not ready. | Can not get MFP status form Network status channel before F/W file is transmitted. | Check PC network settings and IP address. Check MFP network settings and IP address. Do not update F/W when MFP is in power-on stage. |
| Wrong Model. | F/W file is not matched for current machine. | Please check the version of F/W file and machine if it is suitable for MFP. |
| Machine is busy. | F/W update is running. Other MFP functions are running. | Please wait F/W update is completed. Please wait other MFP functions are completed. |
| FW Update Done. *** Please reboot the Machine.*** | F/W update is completed. | Please reboot the Machine. |
| Machine loses communication. ***Please check FW Update Done. Then reboot the Machine.*** | F/W file has transmitted. Polling F/W update progress fail. | Do not reboot engine till Engine Panel display "Firmware Update Done. Please reboot". Then reboot engine. |
| Downloaded file is broken! Do NOT use print, scan, fax and copy function at the same time. | F/W checks the downloaded file. And get wrong checksum. So stop to modify F/W. | Check the downloaded file is not broken. Do not use MFP functions when update firmware. |

TROUBLESHOOTING

| REVISION HISTORY | | |
|------------------|------|-------------------|
| Page | Date | Added/Updated/New |
| | | None |

6. TROUBLESHOOTING

6.1 SERVICE CALL CONDITIONS

See "[Appendices](#)" for the "Error Messages".

6.1.1 SUMMARY

This machine issues an SC (Service Call) code if an error occurs with the machine. The error code can be seen on the operation panel.

Make sure that you understand the following points;

1. All SCs are logged.
2. At first, always turn the main switch off and on if an SC code is displayed.
3. First, disconnect then reconnect the connectors before replacing the PCBs (if the problem concerns electrical circuit boards).
4. First, check the mechanical load before replacing motors or sensors (if the problem concerns a locked motor).

Fusing related SCs

To prevent damage to the machine, the main machine cannot be operated until the fusing related SC has been reset by a service representative.

- Enter the "Engine Maintenance" in the "Maintenance mode".

Press "O.K" in "Fuser SC Reset" with engine maintenance mode, and then turn the main power switch off and on.

6.1.2 ENGINE SC

SC 2xx (Laser Optics Error)

| | |
|-----|---|
| 202 | Polygon motor on timeout error |
| | The polygon mirror motor does not reach the targeted operating speed within 10 sec. after turning. |
| 203 | Polygon motor off timeout error |
| | The polygon mirror motor does not leave the READY status within 20 sec. after the polygon mirror motor switched off. |
| 204 | Polygon motor lock signal error |
| | The signal remains HIGH for 200 ms (or 4times in 50msec polling) while the polygon mirror motor is rotating. |
| | <ul style="list-style-type: none"> ▪ Polygon motor/driver board harness loose or disconnected ▪ Polygon motor/driver board defective ▪ Laser optics unit defective <ol style="list-style-type: none"> 1. Turn the main power off/on the machine. 2. Replace the interface harness of the laser optics unit. 3. Replace the laser optics unit. |
| 220 | Beam Synchronize error |
| | The laser synchronizing detection signal for LD is not output within 400msec after the LD unit has turned on. |
| | <ul style="list-style-type: none"> ▪ Disconnected cable from the laser synchronizing detection unit or defective connection ▪ Defective laser synchronizing detector ▪ Defective LD ▪ Defective ECB <ol style="list-style-type: none"> 1. Check the connectors. 2. Replace the laser optics unit. 3. Replace the ECB. |

| | |
|-----|---|
| 268 | Laser Scanning Unit thermistor error |
| | At power on, the temperature sensor in the optics unit detected a temperature lower than -30°C for more than 4 sec. -or- It detected a temperature higher than 105°C for more than 1sec. |
| | <ul style="list-style-type: none"> ▪ Thermistor disconnected (causes extremely low temperature reading) ▪ Thermistor damaged and short circuited (causes extremely high temperature reading) <ol style="list-style-type: none"> 1. Turn the machine's main power off, and then on. 2. Replace the thermistor. |

SC 4xx (Image Transfer and Transfer Error)

| | |
|-----|---|
| 491 | Bias leak |
| | An error signal is detected for 0.2 seconds when changing the development unit. |
| | <ul style="list-style-type: none"> ▪ Defective transfer roller ▪ Defective high voltage power pack <ol style="list-style-type: none"> 1. Turn the machine's main power off, and then on. |

SC 5xx (Motor and Fusing Error)

| | |
|-----|--|
| 500 | Main motor error |
| | The machine does not detect a main motor lock signal within 2sec after the main motor started to rotate. -or- The machine does not release a main motor lock signal within 2sec after the main motor switched off. -or- The machine detects a main motor lock signal every 100ms for seven times consecutively, after the main motor started to rotate stably. |

Service Call Conditions

| | |
|-----|---|
| | <ul style="list-style-type: none"> ▪ Overload of ▪ Torque load overload ▪ Defective main motor ▪ Disconnect or defective motor harness <ol style="list-style-type: none"> 1. Turn the machine's main power off, and then on. 2. Check or replace the main motor if the torque load is normal. 3. Replace the motor harness. |
| 530 | Exhaust fan Error |
| | The FAN lock signal – High for 10 seconds, after the fan motor started to rotate. |
| | <ul style="list-style-type: none"> ▪ Disconnected or defective motor harness. <ol style="list-style-type: none"> 1. Turn the machine's main power off, and then on. |
| 541 | Fuser thermistor error |
| | The thermistor output is less than 0°C for 5 seconds after the fusing lamp turns ON. |
| | <ul style="list-style-type: none"> ▪ Disconnected or defective thermistor ▪ Disconnected or defective fusing lamp <ol style="list-style-type: none"> 1. Check the harness connection of the thermistor. 2. Replace the fusing unit. <p>★ Important</p> <ul style="list-style-type: none"> ▪ Execute "Engine Maintenance Menu" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated. |
| 542 | Fuser reload error |
| | <p>This SC is issued if one of following conditions occurs:</p> <p>The fusing temperature rises 8°C or less in 1.5 seconds; and this continues 5 times consecutively.</p> <p>-or-</p> <p>The fusing temperature has not reached 45°C within 9 seconds (after the fusing lamp comes ON while the machine is warming-up).</p> <p>-or-</p> <p>The fusing unit does not attain reload temperature within 35 s. (normal temperature) or 65 s (lower temperature – the thermistor output is less than 18°C) after the fusing temperature control starts.</p> |

| | |
|-----|---|
| | <ul style="list-style-type: none"> ▪ Defective or deformed thermistor ▪ Incorrect power supply input at the main power socket <ol style="list-style-type: none"> 1. Defective fusing lamp |
| 543 | High temperature error (Soft) |
| | <ul style="list-style-type: none"> ▪ The detected temperature stays at 225°C for 1 second, and this consecutively occurs 10 times. |
| | <ul style="list-style-type: none"> ▪ Defective ECB ▪ Defective PSU <ol style="list-style-type: none"> 1. Replace the ECB 2. Replace the PSU <p>★ Important</p> <ul style="list-style-type: none"> ▪ Execute "Fuser SC Reset" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated. |
| 544 | High temperature error (hard) |
| | <ul style="list-style-type: none"> ▪ During stand-by mode or a print job, the detected heating roller temperature reaches 250°C. |
| | <ul style="list-style-type: none"> ▪ Defective ECB ▪ Defective PSU <ol style="list-style-type: none"> 1. Replace the ECB 2. Replace the PSU <p>★ Important</p> <ul style="list-style-type: none"> ▪ Execute "Fuser SC Reset" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated. |

| | |
|-----|---|
| 545 | Fuser full heater error |
| | The fuser full heater remained ON at full capacity for more than 9 s after the fusing temperature attains reload temperature. |
| | <ul style="list-style-type: none"> ▪ Deformed thermistor ▪ Thermistor not in the correct position ▪ Defective fusing lamp <ol style="list-style-type: none"> 1. Replace the fusing unit. 2. Replace the fusing lamp. <p>★ Important</p> <ul style="list-style-type: none"> ▪ Execute "Fuser SC Reset" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated. |
| 547 | Zero cross error |
| | <ul style="list-style-type: none"> ▪ The zero cross signal is detected three times even though the fusing lamp relay is off when turning on the main power. ▪ The zero cross signal is not detected for 3 seconds even though the fusing lamp relay is on after turning on the main power or closing the front door. ▪ The detection error occurs twice or more in 11 zero cross signal detections. This error is defined when the detected zero cross signal is less than 45. ▪ The zero cross signal is not detected three times while the main power remains ON. |
| | <ul style="list-style-type: none"> ▪ Defective fusing relay ▪ Defective fusing relay circuit ▪ Shorted +24V fuse on the PSU ▪ Unstable power supply. <ol style="list-style-type: none"> 1. Check the power supply source. 2. Replace the +24V fuse on the PSU. 3. Replace the PSU |
| 559 | Fuser 3times jam error |
| | <p>The paper jam counter for the fusing unit reaches 3. The paper jam counter is cleared if the paper is fed correctly.</p> <p>This SC is activated only when this function is enabled with "Engine Maintenance" (default "OFF").</p> |

| | |
|--|---|
| | <ul style="list-style-type: none"> ▪ Defective fusing unit ▪ Defective fusing control <ol style="list-style-type: none"> 1. Clear this SC to send a command after a jam removal. 2. Turn off this function after a jam removal. <p>★ Important</p> <ul style="list-style-type: none"> ▪ Execute "Fuser SC Reset" to recover the machine after completing the recovery procedure. Otherwise, the machine continues to issue this SC code and cannot be operated. |
|--|---|

SC 6xx (Communication and Other Error)

| | |
|-----|--|
| 669 | EEPROM communication error |
| | An unexpected value exists in the initialization flag of the EEPROM |
| | <ul style="list-style-type: none"> ▪ EEPROM not connected ▪ Defective EEPROM <ol style="list-style-type: none"> 1. Installing the EEPROM. 2. Replacing the EEPROM. |
| 688 | CTL_PRREQ_N signal does not come. |
| | The ECB does not receive a memory address command from the controller 20 seconds after paper is in the position for registration. |
| | <ul style="list-style-type: none"> ▪ Defective controller board ▪ Communication error <ol style="list-style-type: none"> 1. Turn the machine's main power off, and then on. 2. Check if the controller board is firmly connected to the ECB. |



6.1.3 CONTROLLER SC


SC 8xx

| | |
|-----|---|
| | Scan lock error |
| 820 | By an unexpected reason, the controller error occurred. |
| | Turn the machine's main power off, and then on. |

6.2 IMAGE PROBLEMS

6.2.1 OVERVIEW

Image problems may appear at regular intervals that depend on the circumference of certain components. The following diagram shows the possible symptoms (black or white dots at regular intervals).




- Abnormal image at 29.8 mm intervals: Charge roller
- Abnormal image at 37.7 mm intervals: Registration roller
- Colored spots at 37.9 mm intervals: Print cartridge (Development roller)
- Abnormal image at 45.8 mm intervals: Transfer roller
- Colored spots at 75.3 mm intervals: Print cartridge (OPC drum)
- Abnormal image at 94.2 mm intervals: Fusing unit (Pressure roller)
- Abnormal image at 93.1 mm intervals: Fusing unit (Hot roller)
- Abnormal image at 100.5 mm intervals: Paper feed roller

6.2.2 TEST PAGE PRINTING

When you check an image problem or other problems, it might be necessary to print a test page. Follow the test page print procedure below to print a test page.

Test Page Print Procedure

1. Press the "User Tools".
2. Press the "Up" or "Down" keys to select "Printer Features" and then press the "OK" key.
3. Press the "Up" or "Down" keys to select "List/Test Print" and then press the "OK" key.
4. Press the "Up" or "Down" keys to select "Test Page" and then press the "OK" key.
5. Press the left key "Yes" of the "Selection keys" to print the test page to preview the settings.
 - Test page sample



m118t100




6.2.3 TEST PATTERN PRINTING

Follow the test pattern print procedure below to print a test pattern.

Test Pattern Print Procedure

1. Enter the "Maintenance Mode".
2. Select "Engine Maintenance", and then press "OK" key.
3. Select "Test Pattern", and then press "OK" key.
4. The following three test pattern pages (Checker flag/ Grid pattern/ Trimming pattern) are printed.

- Test pattern samples



m016t502

6.2.4 DARK LINES IN HALFTONE AREAS AT 75MM INTERVALS

Using the machine in a room where humidity level is too low may cause dark lines in halftone areas at 75mm intervals. This is because low-humidity conditions tend to cause variations in light sensitivity across the surface of the drum.

Selecting [On] for [Low Humidity Mode] under [System Settings] (User Tools) may help to prevent these lines from appearing.


When the humidity mode setting is enabled, the drum is rotated slightly every 15 minutes. This keeps the light sensitivity constant across the entire surface of the drum.

6.3 JAM

6.3.1 JAM SENSOR LAYOUT


There are the sensors of the jam detection as shown below.

Paper Jam



1. Registration Sensor
2. Tray2 Paper Feed Sensor
3. Inverter Sensor
4. Paper Exit Sensor
5. Relay Sensor


Original Jam (AFD)



1. ADF Feed Sensor
2. Original Set Sensor

Original Jam (ARFD)


Single page scan



m118t301

1. ADF Feed Sensor
2. Original Set Sensor

Second page scan



m118t302

1. Original Reverse Sensor

Trouble-shooting

6.3.2 JAM MESSAGE LIST

Here is a list of common jam messages, a description of the causes.

See the drawing shown above to check the sensor location.

Paper Jam

Related to jam code

| Jam message | Cause | Sensor |
|---------------------------------|---|-----------------------------|
| Misfeed: Paper Tray | Paper does not reach registration sensor (bypass tray) | Registration sensor [1] |
| Misfeed: Tray 1 | Paper does not reach registration sensor (tray1) | Registration sensor [1] |
| Misfeed: Tray 2 | Paper does not reach tray2 convey sensor | Tray2 paper feed sensor [2] |
| | Paper does not reach registration sensor | Registration sensor [1] |
| Misfeed: Dup. Unit Remove Paper | Paper does not reach registration sensor (duplex feed tray) | Registration sensor [1] |
| | Paper does not reach duplex entry sensor | Relay sensor [5] |
| | Paper does not reach duplex exit sensor | Inverter sensor [3] |
| Internal Misfeed | Paper stayed on registration sensor | Registration sensor [1] |
| | Paper does not reach exit sensor | Paper exit sensor [4] |
| Misfeed: Std. Tray | Paper stayed on exit sensor | Paper exit sensor [4] |

Related to initialize jam

| Jam message | Cause |
|---------------------------------|-----------------------------|
| Misfeed: Tray 2 | Tray2 paper feed sensor [2] |
| Internal Misfeed | Registration sensor [1] |
| Misfeed: Stnd. Tray | Paper exit sensor [4] |
| Misfeed: Dup. Unit Remove Paper | Relay sensor [5] |
| | Inverter sensor [3] |

Original Jam

| Jam message | Cause |
|---|--|
| ADF Original Misfeed Open ADF Cover and Remove paper. | ADF Feed sensor [6], [8] Original set sensor [7], [9] Original reverse Sensor [10] |


ENERGY SAVE

| REVISION HISTORY | | |
|------------------|------|-------------------|
| Page | Date | Added/Updated/New |
| | | None |

7. ENERGY SAVE

7.1 ENERGY SAVER MODES

Customers should use energy saver modes properly, to save energy and protect the environment.



The backlight of the screen is turned off and "Energy Saver Mode1" appears on the screen, and then the fusing lamp is turned off and "Energy Saver Mode2" appears on the screen.

The area shaded grey in this diagram represents the amount of energy that is saved when the timers are at the default settings. If the timers are changed, then the energy saved will be different. For example, if the timers are all set to 240 min., the grey area will disappear, and no energy is saved before 240 min. expires.

Timer Settings

The user can set these timers with User Tools (Admin. Tools > Power Saver Mode> EnergySaver Mode1 or Mode2)

- Energy Saver Mode 1 (30 sec.): This can be only turned on or off.
- Energy Saver Mode 2 (1 to 240 min.): This can be turned on or off and timer setting is adjustable (default: 1min.).

Return to Stand-by Mode

Energy Saver Mode 1

- Recovery time: 10 sec.

Energy Saver Mode 2

- Recovery time: 20 sec.

Recommendation

We recommend that the default settings should be kept.

- If the customer requests that these settings should be changed, please explain that their energy costs could increase, and that they should consider the effects on the environment of extra energy use.
- If it is necessary to change the settings, please try to make sure that the Energy Saver Mode 2 Timer is not too long. Try with a shorter setting first, such as 30 min., then go to a longer one (such as 60 min.) if the customer is not satisfied.
- If the timers are all set to the maximum value, the machine will not begin saving energy until 240 minutes has expired after the last job. This means that after the customer has finished using the machine for the day, energy will be consumed that could otherwise be saved.

7.2 PAPER SAVE

7.2.1 EFFECTIVENESS OF DUPLEX/COMBINE FUNCTION

Duplexing and the combine functions reduce the amount of paper used. This means that less energy overall is used for paper production, which improves the environment.

1. Duplex:

Reduce paper volume in half!



d062d102

2. Combine mode:

Reduce paper volume in half!



d062d100

3. Duplex + Combine:

Using both features together can further reduce paper volume by 3/4!



d062d101

To check the paper consumption, look at the total counter and the duplex counter.

The total counter counts all pages printed.

- For one duplex page, the total counter goes up by 2.
- For a duplex job of a three-page original, the total counter goes up by 3.

The duplex counter counts pages that have images on both sides.

- For one duplex page, the duplex counter goes up by 1.
- For a duplex job of a three-page original, the duplex counter will only increase by 1, even though two sheets are used.

Total counter

This machine has a total sides printed counter only (so a duplex print is counted as two, not one).

You can check the total counter in the "Maintenance mode" or the "User Tools".

- Maintenance mode
"Engine Maintenance" > "Display Info" > "Counter"
- User Tools
"Print List/Report" > "Configuration Page" or "Maintenance Page"

The following table shows paper savings and how the counters increase for some simple examples of single-sided and duplex jobs

Duplex mode:

| Originals | Simplex Sheet used | Duplex Sheets used | Paper Saved | Total counter |
|-----------|--------------------|--------------------|-------------|---------------|
| 1 | 1 | 1 | 0 | 1 |
| 2 | 2 | 1 | 1 | 2 |
| 3 | 3 | 2 | 1 | 3 |
| 4 | 4 | 2 | 2 | 4 |
| 5 | 5 | 3 | 2 | 5 |
| 10 | 10 | 5 | 5 | 10 |
| 20 | 20 | 10 | 10 | 20 |

If combine mode is used, the total and duplex counters work in the same way as explained previously. The following table shows paper savings and how the counters increase for some simple examples of duplex/combine jobs.

2 in 1 mode:

| Originals | Simplex Sheet used | Duplex Sheets used | Paper Saved | Total counter |
|-----------|--------------------|--------------------|-------------|---------------|
| 1 | 1 | 1 | 0 | 1 |
| 2 | 2 | 1 | 1 | 1 |
| 3 | 3 | 2 | 1 | 2 |
| 4 | 4 | 2 | 2 | 2 |
| 5 | 5 | 3 | 2 | 3 |
| 10 | 10 | 5 | 5 | 5 |
| 20 | 20 | 10 | 10 | 10 |

Paper Save

Duplex + 2 in 1 mode:

| Originals | Simplex Sheet used | Duplex Sheets used | Paper Saved | Total counter |
|-----------|--------------------|--------------------|-------------|---------------|
| 1 | 1 | 1 | 0 | 1 |
| 2 | 2 | 1 | 1 | 1 |
| 3 | 3 | 1 | 2 | 2 |
| 4 | 4 | 1 | 3 | 2 |
| 5 | 5 | 2 | 3 | 3 |
| 6 | 6 | 2 | 4 | 3 |
| 7 | 7 | 2 | 5 | 4 |
| 8 | 8 | 2 | 6 | 4 |
| 9 | 9 | 3 | 6 | 5 |
| 10 | 10 | 3 | 7 | 5 |
| 11 | 11 | 3 | 8 | 6 |
| 12 | 12 | 3 | 9 | 6 |

M118/M119
SERVICE MANUAL APPENDICES

M118/M119 APPENDICES

TABLE OF CONTENTS

| | |
|---|------------|
| 1. APPENDIX: SPECIFICATIONS | 1-1 |
| 1.1 GENERAL SPECIFICATIONS | 1-1 |
| 1.1.1 GENERAL SPECIFICATIONS | 1-1 |
| 1.1.2 PRINTER | 1-4 |
| 1.1.3 COPIER | 1-5 |
| 1.1.4 SCANNER | 1-7 |
| 1.1.5 FAX..... | 1-8 |
| Fax transmission and reception | 1-8 |
| Internet Fax transmission and reception | 1-10 |
| 1.2 SUPPORTED PAPER SIZES | 1-11 |
| 2. APPENDIX: SP MODE TABLE | 2-1 |
| 2.1 SERVICE MENU..... | 2-1 |
| 3. APPENDIX: TROUBLESHOOTING GUIDE | 3-1 |
| 3.1 SERVICE CALL CONDITIONS..... | 3-1 |
| 3.2 ERROR MESSAGES | 3-2 |
| 3.2.1 OVERVIEW | 3-2 |
| 3.2.2 ERROR MESSAGES LIST | 3-2 |
| 3.2.3 FAX ERROR CODE..... | 3-13 |
| Fax Error Code Structure | 3-13 |
| Fax Error Code Table..... | 3-15 |
| Internet Fax Error Code Table..... | 3-17 |

APPENDIX: SPECIFICATIONS

| REVISION HISTORY | | |
|------------------|------|-------------------|
| Page | Date | Added/Updated/New |
| | | None |

1. APPENDIX: SPECIFICATIONS

1.1 GENERAL SPECIFICATIONS

1.1.1 GENERAL SPECIFICATIONS

| | | |
|----------------|--------------------------|--|
| Configuration | Desktop | |
| Paper capacity | Main tray | 250 sheets (80g/m ²) 100 postcards |
| | By-pass tray | 50 sheets (80g/m ²) 8 envelopes 20 postcards |
| | Optional paper feed unit | Plain paper: 250 sheets (80g/m ²) |
| | Output tray | Face down: 125 sheets |
| Paper size | Main tray | A4, A5, Letter, Legal, B5, HLT, A6, Executive, Postcard Custom size: Max: 216 x 356mm (8.5 x 14 inch) Min: 100 x 148mm (3.937 x 5.8 inch) |
| | By-pass tray | A4, A5, A6, Letter, Legal, HLT, Executive, Postcard, B5, Envelope Custom size: Max.: 216 x 356mm (8.5 x 14 inch) Min.: 90 x 140mm (3.5 x 5.5 inch) |
| | Duplex | A4, Letter, Legal |
| | Optional paper feed unit | A4, LT, LG, B5, HLT, A5 |

General Specifications

| | | |
|--------------------------|--|---|
| Paper weight | Main tray | 52-162 g/m ² (14-43 lb) |
| | By-pass tray | 52-162 g/m ² (14-43 lb) |
| | Optional paper feed unit | 60-105 g/m ² (16-28 lb) A setting for outside of normal specifications paper (60 g/m ² - 105 g/m ²) is provided. With this setting, it may be possible to print properly on outside of normal specifications paper. |
| ARDF | Paper weight | 52-105 g/m ² (14-28 lb) |
| | Capacity | 50 sheets |
| | Width | 139.7 to 216mm (5.5 to 8.5 inch) |
| | Length | 139.7 to 355.6mm (5.5 to 14 inch) |
| ADF | Paper weight | 52-105 g/m ² (14-28 lb) |
| | Capacity | 35 sheets |
| | Width | 139.7 to 216mm (5.5 to 8.5 inch) |
| | Length | 139.7 to 355.6mm (5.5 to 14 inch) |
| Machine size (W x D x H) | M118: 420 x 397 x 442 mm (16.6 x 15.7 x 17.4 inch) M119: 420 x 397 x 463 mm (16.6 x 15.7 x 18.3 inches) Without Option | |
| Weight | M118: 17.5 kg (38.6 lb) M119: 19.0 kg (41.9 lb) ▪ With a starter AIO cartridge. | |
| Energy Saver Mode | Selectable 1 to 240 minutes (1 minute steps) | |

| | | |
|------------------------|---|--|
| Power consumption | Maximum | NA/TW: Less than 850 W (energy star compliant) EU/AP/CN: Less than 895 W (energy star compliant) |
| | Ready mode | 120W |
| | Power save mode | 70 W (energy saver mode1) 10 W (energy saver mode2) |
| Power | NA | 120 V, 60Hz ± 3Hz |
| | TW | 110 V, 60Hz ± 3Hz |
| | EU/AP/CN | 220 - 240 V, 50/60Hz ± 3Hz |
| Noise | Printing | Less than 65.8 dB (A) |
| | Standby Mode | Less than 40 dB (A) |
| | Energy Save Mode | Less than 40 dB (A) |
| Warm up time | Less than 20 seconds | |
| Machine life | 5 years, 350,000 prints (whichever comes first) | |
| Environmental Standard | Energy star program (M119) | |
| Laser type | Class I | |

1.1.2 PRINTER

| | | |
|------------------|--|--------------------------------|
| Print speed | Simplex | 30 ppm LT, 28 ppm A4 (600 dpi) |
| | Duplex (M119 only) | 15 ppm LT, 14 ppm A4 (600 dpi) |
| Printer drivers | PCL, PS3 | |
| Font | 80 fonts | |
| Resolution | 1200 x 1200, 600 x 600 dpi | |
| Toner save mode | Supported | |
| First print time | Less than 8 seconds | |
| Duplex print | Supported (M119 only) | |
| PC interface | USB 2.0, 10BASE-T/100BASE-TX | |
| Network | Protocol | TCP/IP, IPP |
| Memory | Standard | 128MB |
| Operation System | PCL: Windows XP/Vista/7 and Windows Server 2003/2003 R2/2008/2008 R2 PS3: Windows XP/Vista/7 and Windows Server 2003/2003 R2/2008/2008 R2, and Mac OS X 10.3 or later | |

1.1.3 COPIER

| | | | |
|-------------------------|-------------------------------|---|--|
| 1st copy speed | | Less than 12 sec. | |
| Maximum original size | | Flatbed | A4 (210 x 297mm) / Letter (215.9 x 279.4mm) |
| | | ADF/ARDF | A4 (210 x 297mm) / Letter (215.9 x 279.4mm)/ Legal (215.9 x 355.6mm) |
| Copy Speed | Single Document | Flatbed | 28 cpm (A4), 30 cpm (LT) |
| | Multiple Copy | ADF/ARDF | 28 cpm (A4), 30 cpm (LT) |
| | Multiple Document Single Copy | ADF/ARDF | 20 cpm |
| Multiple copy | | Up to 99 | |
| Resolution (H x V) | | Scanning | 600 x 600 dpi (Flatbed), 600 x 300 dpi (ADF/ARDF) |
| | | Printing | 600 x 600 dpi |
| Grayscale | | 256 levels | |
| Reduction / Enlargement | | Fix | NA: 50, 65, 78, 93, 129, 155, 200, 400% EU: 50, 71, 82, 93, 122, 141, 200, 400% |
| | | Custom | 25 - 400% in 1% steps |
| Copy mode | | Text/ Photo/ Mixed | |
| Memory copy | | Yes | |
| Duplex copy | | Yes (M119 only) | |
| ID card copy | | Yes | |
| Interrupt copy | | No | |
| Combine copy | | 2 in 1, 4 in 1 (ADF/ARDF only for A4/ LT) | |

General Specifications

| | |
|--------------------------------|---|
| APS/ AMS | No/No |
| Auto Tray Switch | No |
| Directional Magnification | No |
| Directional Size Magnification | No |
| Photo Mode | Yes |
| Auto Start | No |
| User Program | No |
| Electronic Sorting | Standard (collation, ADF/ARDF only), Max. A4/ LT, LG |
| Image Rotation | No |
| Series Copy | No |

1.1.4 SCANNER

| | | |
|---|----------|---|
| Scanning Device | | CCD array image-sensor |
| Resolution | | Scanner: 1200 x 1200 dpi |
| | | Driver: Max. 19200 x 19200 dpi (interpolated) |
| Gray scale | | 256 levels |
| Scan modes/ speed (A4, 300dpi, USB2.0) | | ADF/ARDF Black&White: less than 5 sec. / Gray Scale: less than 5 sec. / Color: less than 10 sec |
| | | Platen Black&White: less than 5 sec. / Gray Scale: less than 5 sec. / Color: less than 10 sec |
| Maximum original size | Platen | Width max: Up to 216mm, Length max: Up to 297mm |
| | ADF/ARDF | Width max: Up to 216mm, Length max: Up to 356mm |
| Scan Depth | | 48 bits color processing (input), 24 bits color processing (output) |
| PC Interface | | USB2.0, 10BASE-T/100BASE-TX |
| TWAIN Compliment | | TWAIN, WIA |
| Scanner utilities and Drivers | | TWAIN Driver, Scanner utility (PageManager) |

1.1.5 FAX

Fax transmission and reception

| | | |
|-----------------------------|---|---------------------------------|
| Network | PSTN/ PBX | |
| Compatibility | T30 (ITU-T Super G3) | |
| Transmission Speed | Approx. 3sec | |
| Coding system | MH/MR/MMR/JBIG | |
| Contrast control | 3 Level | |
| Telephone Connection | Standard: One connection | |
| Answering Machine Interface | Standard | |
| Monitor Speaker | 3 Level | |
| Document size | ADF/ARDF Width | 139.7 to 215.9mm (5.5" to 8.5") |
| | ADF/ARDF Length | 139.7 to 355.6mm (5.5" to 14") |
| | Flatbed Width | 216mm |
| | Flatbed Length | 297mm |
| Scanning width | Max. 210 mm (8.3") | |
| Printing width | Max. 208 mm (8.2") | |
| Gray scale | 256 levels | |
| Polling type | None | |
| Resolution | Standard: 200dpi x 100dpi (8 dot/mm x 3.85 line/mm) Fine/Photo: 200dpi x 200dpi (8 dot/mm x 7.7 line/mm) | |
| Scanning Speed | Less than 5 sec. (A4 SEF, 200 dpi) | |
| Modem Speed | Automatic Fallback: 33600, 31200, 28800, 26400, 24000, 21600, 19200, 16800, 14400, 12000, 9600, 7200, 4800, 2400bps | |

| | |
|----------------------|-----------------------------------|
| SAF Memory | 100 pages (ITU No.1 chart) |
| Memory Backup | 1 hour |
| One-touch dial | 20 |
| Abbreviated dial | 200 |
| Broadcasting | 100 stations |
| Communication source | Public switched telephone network |
| PC Fax utility | Available |
| Automatic re-dial | Available |
| Auto Answer | 3-5 rings (Default 3 rings) |
| LDAP authentication | Available |
| LDAP address search | Available |

Internet Fax transmission and reception

| | | |
|------------------------------------|---|--|
| Interface | Ethernet (10BASE-T, 100BASE-TX) | |
| Communication protocols | Transmission: SMTP, TCP/IP Reception: POP3, TCP/IP | |
| Transmission function | E-mail | |
| E-mail format | Single/Multi-part, MIME Conversion Attached file forms (transmission): TIFF-S (MH encoding) Attached file forms (reception): TIFF-S/TIFF-F (MH/MR/MMR encoding) | |
| Authentication method | SMTP-AUTH, POP before SMTP, A-POP | |
| Original size | A4 (Length is up to 356 mm) | |
| Scan line density | 8 dots per mm × 3.85 line per mm (200 × 100 dpi) 8 dots per mm × 7.7 line per mm (200 × 200 dpi) | |
| Destination machine specifications | Communication protocols | Transmission: SMTP, TCP/IP Reception: POP3, TCP/IP |
| | E-mail format | Format: MIME, Base64 Content-Type: Image/tiff, Multipart/mixed (text/plain, Image/tiff (attached file forms)) |
| | Data format | Profile: TIFF-S Encoding: MH Original size: A4 Resolution (dpi): 200 × 100, 200 × 200 |

1.2 SUPPORTED PAPER SIZES

| | |
|---|--|
| A | Supported, with size molded into tray. Need to select paper size by operation panel/driver. |
| B | Supported but size is not molded into tray. Need to select paper size by operation panel/driver. |
| C | Need to input paper size by operation panel and driver. |
| N | Not supported. |

| Type | SEF/ LEF | Size | Input Tray | | | Auto Duplex |
|----------|-------------|-----------------------|------------------|---------------|----------------|----------------|
| | | | Standard Tray | Option PFU | Bypass Tray | |
| A4 | SEF | 210x297 | A | A | B | B |
| B5 | SEF | 182x257 | A | A | B | N |
| A5 | SEF | 148x210 | A | A | B | N |
| | LEF | 210x148 | N | N | C | N |
| B6 | SEF | 128x182 | B | N | B | N |
| | LEF | 182x128 | N | N | N | N |
| A6 | SEF | 105x148 | B | N | B | N |
| | LEF | 148x105 | N | N | N | N |
| Postcard | SEF | 100 x 148 | C | N | C | N |
| | LEF | 148 x 100 | N | N | N | N |
| | SEF | 200 x 148 | C | N | C | N |
| | LEF | 148 x 200 | C | N | C | N |
| Legal | SEF | 8 $\frac{1}{2}$ "x14" | A | A | B | B |
| Letter | SEF | 8 $\frac{1}{2}$ "x11" | A | A | B | B |

Supported Paper Sizes

| Type | SEF/ LEF | Size | Input Tray | | | Auto Duplex |
|-----------------|-------------|---|------------------|---------------|----------------|----------------|
| | | | Standard Tray | Option PFU | Bypass Tray | |
| Half Letter | SEF | 5 ¹ / ₂ " x 8 ¹ / ₂ " | B | B | B | N |
| | LEF | 8 ¹ / ₂ " x 5 ¹ / ₂ " | N | N | N | N |
| Executive | SEF | 7 ¹ / ₄ "x10 ¹ / ₂ " | A | N | B | N |
| F | SEF | 8" x 13" | B | N | N | N |
| Foolscap | SEF | 8 ¹ / ₂ " x 13" | B | N | N | N |
| Folio | SEF | 8 ¹ / ₄ " x 13" | B | N | N | N |
| 16 Kai | SEF | 195 x 267 | B | N | B | N |
| Env. #10 | SEF | 4 ¹ / ₈ " x 9 ¹ / ₂ " | N | N | B | N |
| Env. Monarch | SEF | 3 ⁷ / ₈ " x 7 ¹ / ₂ " | N | N | B | N |
| Env. C5 | SEF | 162 x 229 | N | N | B | N |
| Env. C6 | SEF | 114 x 162 | N | N | B | N |
| Env. DL | SEF | 110 x 220 | N | N | B | N |
| | Width | 100-216mm | C | N | C | N |
| | Length | 148-156mm | C | N | C | N |
| | Width | 90-216mm | N | N | C | N |
| | Length | 140-356mm | N | N | C | N |

APPENDIX:
SP MODE TABLE

| REVISION HISTORY | | |
|-------------------------|-------------|--------------------------|
| Page | Date | Added/Updated/New |
| | | None |

2. APPENDIX: SP MODE TABLE

2.1 SERVICE MENU

See "Main Chapters" for "Service Program Mode".

Appendix:
SP Mode
Table

APPENDIX:
TROUBLESHOOTING GUIDE

| REVISION HISTORY | | |
|-------------------------|-------------|--------------------------|
| Page | Date | Added/Updated/New |
| | | None |

3. APPENDIX: TROUBLESHOOTING GUIDE

3.1 SERVICE CALL CONDITIONS

See "Main Chapters" for "Service Call Conditions".

3.2 ERROR MESSAGES

3.2.1 OVERVIEW

Error codes will be displayed on the LCD panel if the machine has a problem. These can be viewed by a customer.

3.2.2 ERROR MESSAGES LIST

| Message | Causes | Solutions |
|-----------------------------------|--|--|
| 2XXX14 | The machine was not able to print the received fax, or the machine's memory reached capacity while receiving a fax because the document was too large. | <ul style="list-style-type: none"> ▪ The paper tray was empty. Load paper in the paper tray. See User Guide. ▪ The tray set for [Select Paper Tray] under [Fax Features] did not contain A4, Letter, or Legal size paper. Load valid size paper in the tray, and configure the paper size settings under [System Settings] accordingly. ▪ A cover or tray was open. Close the cover or tray. ▪ There was a paper jam. Remove the jammed paper. See User Guide. ▪ A print cartridge was empty. Replace the print cartridge. See User Guide. ▪ The received fax was too large. Ask the sender to resend the document in parts as several smaller individual faxes, or to send at a lower resolution. |
| ADF Cover Open Close ADF Cover | The ARDF/ADF cover is open. | Close the cover completely. |

| Message | Causes | Solutions |
|--|--|--|
| ADF Orig. Misfeed Open ADF Cover and remove paper. | An original has been jammed inside the ARDF or ADF. | <ul style="list-style-type: none"> ▪ Remove jammed originals, and then place them again. See User Guide. ▪ Check the originals are suitable for scanning. See the user's guide. |
| Available: 2 Sided Copy A4/LG/LT | 2-sided copy could not be performed because the tray does not contain the valid size paper, which are A4, Letter, or Legal. | <ul style="list-style-type: none"> ▪ Specify the tray containing the A4, Letter, or Legal size paper in the [Select Paper] setting. See User Guide. ▪ Specify A4, Letter, or Legal for the tray selected for printing copies. See the user's guide. |
| Available: IDCard Copy A4 or 8 1/2 x 11 | ID card copy could not be performed because the tray does not contain the valid size paper, which are A4 or Letter size. | <ul style="list-style-type: none"> ▪ Set the machine to print copies using the A4 or Letter size paper in the [Select Paper] setting. See User Guide. ▪ Specify the A4 or Letter size paper for the tray selected for printing copies. See the user's guide. |
| Busy | Fax transmission could not be completed because the destination's line was busy. | Wait for a while and send the fax again. |
| Cannot Copy This Setting Comb.: 2 on 1 / 4 on 1 | Combined copying could not be performed because the tray does not contain the valid size paper, which are A4, Letter, or Legal size. | <p>Set the machine to print copies using the A4, Letter, or Legal size paper in the [Select Paper] setting. See User Guide.</p> <p>Specify the A4, Letter, or Legal size paper for the tray selected for printing copies. See User Guide.</p> |

Error Messages

| Message | Causes | Solutions |
|--------------------------------------|---|---|
| Cannot copy. Set original to ADF. | Combined copying/2-sided copying could not be performed because the originals were not placed in the ARDF or ADF. | <ul style="list-style-type: none"> ▪ Use the ARDF or ADF, even when copying a single sheet. ▪ If you need to use the exposure glass, turn off combined copying/2-sided copying in [Duplex/Combine] under copy settings, and then try again. See the user's guide. |
| Check Paper Size | The paper size set for the document differs from the size of the paper in the indicated tray. | Press [FormFeed] to begin printing, or press [JobReset] to cancel the job. |
| Check Paper Type | The paper type set for the document differs from the type of the paper in the indicated tray. | Press [FormFeed] to begin printing, or press [JobReset] to cancel the job. |
| Connection Failed | The line could not be connected correctly. | <ul style="list-style-type: none"> ▪ Confirm that the telephone line is properly connected to the machine. ▪ Disconnect the telephone line from the machine, and connect a standard telephone in its place. Confirm that you can make calls using the telephone. If you cannot make calls this way, contact your telephone company. |
| Cover open | A cover is open. | Close the cover completely. |
| Dest. is not Programmed | No Quick Dial entry is associated with the One Touch button you pressed. | <ul style="list-style-type: none"> ▪ Press a different One Touch button. ▪ Assign a registered destination to the One Touch button. See the user's guide. |

| Message | Causes | Solutions |
|--|---|---|
| Dial Failed | The fax could not be sent. | <ul style="list-style-type: none"> ▪ Confirm that the fax number you dialed is correct. ▪ Confirm that the destination is a fax machine. ▪ Confirm that the line is not busy. ▪ You may need to insert a pause between dial digits. Press the [Pause/Redial] key after, for example, the area code. |
| Exceeded Max.E-mail Size | The scan file exceeds the size limit for files that can be sent through e-mail. | <ul style="list-style-type: none"> ▪ Configure [Resolution] under scanner settings to reduce the scanning resolution. See the user's guide. ▪ Configure [Max. E-mail Size] under scanner settings to increase the allowed size. See the user's guide. |
| Failed to Access File Press Clear key | The Scan to USB function failed because the machine could not access the USB flash disk properly. | Use a USB flash disk that is not password- or write-protected. |
| Failed to Create File Press Clear key | The Scan to USB function failed because there was not enough memory on the USB flash disk. | Use a USB flash disk with enough memory. |
| Fax Job Memory Overflow | The number of fax jobs in memory (unsent or unprinted faxes) has reached maximum, so new jobs cannot be stored. | Wait until pending jobs have been transmitted or printed. |

Error Messages

| Message | Causes | Solutions |
|----------------------|--|---|
| I-Fax POP3 fails | Connection to the POP3 server failed. | <ul style="list-style-type: none"> ▪ Confirm that the network cable is properly connected to the machine. ▪ Confirm that the network settings such as IP address, DNS, and POP3 settings have been configured properly (make sure that no double-byte character is used). See the user's guide. |
| Indep.Sply.Prt.Cart. | A non-supported print cartridge is installed. | Remove and replace it with a print cartridge specified by an authorized dealer. |
| Internal Misfeed | Paper has been jammed in the machine. | Remove the jammed paper. See the user's guide. |
| Memory Almost Full | Memory has almost reached capacity during sort copy. | If several originals are still to be scanned, it is recommended to start printing now, and copy the remaining originals separately. If originals are being scanned from the ARDF or ADF, remove any remaining pages from the ARDF or ADF. |

| Message | Causes | Solutions |
|-----------------|---|---|
| Memory Overflow | <ul style="list-style-type: none"> ▪ The data is too large or complex to print. ▪ If you try to print a Locked Print file stored in the machine with the printer driver's [Resolution] set to [1200 × 600 dpi] or higher in the [Print Quality] tab, printing may be canceled depending on the machine's current memory usage. | <ul style="list-style-type: none"> ▪ Select [600 × 600 dpi] in [Resolution] under [Printer Features] to reduce the size of data. See User Guide. ▪ If using the PCL6 printer driver, set [Resolution] in [Print Quality] to [600 × 600 dpi]. If using the PostScript 3 printer driver, set [Print Quality:] in [Graphics] to [600 × 600 dpi]. ▪ Print or delete other Locked Print files in the machine, and then print the Locked Print file that the machine failed to print. Alternately, resend the Locked Print file to the machine with [Resolution] set to [600 × 600 dpi], and then print the Locked Print file. |
| Memory Overflow | <ul style="list-style-type: none"> ▪ The machine's memory reached capacity while scanning the first page of the original to store a fax job in memory before transmission. ▪ The machine's memory reached capacity while sending a fax via LAN-Fax. ▪ The machine's memory reached capacity while storing a fax in memory in Memory Transmission mode. | Resend the fax in parts as several smaller individual faxes, or send at a lower resolution. |

Error Messages

| Message | Causes | Solutions |
|------------------------------------|---|--|
| Memory Overflow TX Cancel | Memory has reached capacity while scanning the second or later pages of the original when trying to send a fax in Memory Transmission mode. | Press [TX] to send only the pages that have been scanned in memory, or press [Cancel] to cancel. |
| Misfeed: Bypass Tray | Paper has been jammed in the bypass tray. | Remove the jammed paper. See the user's guide. |
| Misfeed: Dup. Unit Remove Paper | Paper has been jammed in the duplex unit. | Remove the jammed paper. See the user's guide. |
| Misfeed: Std. Tray | Paper has been jammed in the paper exit area. | Remove the jammed paper. See the user's guide. |
| Misfeed: Tray 1 | Paper has been jammed in the tray 1 paper input area. | Remove the jammed paper. See the user's guide. |
| Misfeed: Tray 2 | Paper has been jammed in the tray 2 paper input area. | Remove the jammed paper. See the user's guide. |
| Net Communication Error | Connection with the server was lost while sending or receiving data. | Contact the network administrator. |
| Network is not Ready | A scanned file could not be sent because the machine has not received IP address information from the DHCP server completely. | Wait until the machine receives the IP address information completely, and then try the operation again. |
| On Hook or Stop key | The machine has been off-hook for an extended period of time. | Put down the handset or press the [Clear/Stop] key. |
| Out of Paper: X | The indicated tray has run out of paper. | Load paper to the indicated tray. See User Guide. |
| Please Restart Machine | The machine needs to be restarted. | Turn off the power, and then turn it back on. |

| Message | Causes | Solutions |
|---|--|--|
| Print Cart. Set Error | The print cartridge has not been installed or has not been installed correctly. | Reinstall the print cartridge. See the user's guide. |
| Remove Paper: Bypass Tray | The machine failed to proceed with the print job, because tray 1 or tray 2 was specified as the input tray but paper was set in the bypass tray. | Remove paper from the bypass tray. |
| Replace Required Soon: Print Cartridge | The print cartridge is almost empty. | Prepare a new print cartridge. |
| Replacement Required: Fusing Unit | The fusing unit is no longer usable, and must be replaced. | Replace the fusing unit. ☛ p.2-1 "Service Menu" |
| Replacement Required: Paper Feed Roller | The paper feed roller is no longer usable, and must be replaced. | Replace the paper feed roller. ☛ p.2-1 "Service Menu" |
| Replacement Required: Print Cartridge | The machine has run out of toner. | Replace the print cartridge. See the user's guide. |
| Replacement Required: Transfer Roller | The transfer roller is no longer usable, and must be replaced. | Replace the transfer roller. ☛ p.2-1 "Service Menu" |
| RX Comm. Error | A reception error occurred, and the fax could not be received correctly. | If possible, contact the sender of the fax and ask them to resend it. |
| Scan (NW) Disconnected | A scanned file could not be sent because the Ethernet cable was not connected properly. | Reconnect the Ethernet cable properly, and then try the operation again. |

Error Messages

| Message | Causes | Solutions |
|---|--|---|
| Scan (USB) Disconnected | The USB cable was disconnected while scanning from a computer. | Reconnect the USB cable properly, and then try the operation again. |
| Server Connection Failed | A scanned file could not be sent because the destination could not be reached. | Confirm that the destination is registered correctly, and then try the operation again. |
| Server Response Error | An error occurred in communication with the server before beginning transmission. | Confirm that the destination is registered correctly, and then try the operation again. If the problem could not be solved, contact the network administrator. |
| Service call - X | A fatal hardware error has occurred, and the machine cannot function. |  p.3-1 "Service Call Conditions" |
| Set Correct Paper | The tray set for [Select Paper Tray] under [Fax Features] does not contain A4, Letter, or Legal size paper. | While the message is displayed, press the [OK] key. A menu for changing the paper size of the current tray appears. Load A4/Letter/ Legal size paper in the tray, and then select the corresponding paper size using [] [] keys and press the [OK] key. The machine will then print out the fax. Note that the paper size setting for the tray under system settings will be changed. See the user's guide. |
| Set Original to ADF Cannot use exposure glass with set. in [Scan Size]. | Scanning could not be performed because the originals were not placed in the ARDF or ADF, even though the machine is set to scan originals larger than A4/Letter size. | <ul style="list-style-type: none"> ▪ Use the ARDF or ADF, even when scanning A4/Letter or smaller size originals. ▪ If you need to use the exposure glass, set A4/Letter or smaller size in [Scan Size] under scanner settings, and then try again. See the user's guide. |

| Message | Causes | Solutions |
|---------------------------------------|---|--|
| Sort Copy was Cancelled | The machine's memory reached capacity while originals were being scanned from the ARDF or ADF to perform sort copying. | Press [Exit] to print the originals that were successfully scanned into memory. Then, copy again the originals left in the ARDF or ADF. |
| TX Comm. Error | A transmission error occurred, and the fax could not be transmitted correctly. | If the [Auto Redial] setting is enabled, the machine will redial the number and try again. If all attempts fail, or if the machine is in Immediate Transmission mode, the fax will not be transmitted. Try the operation again. |
| Unavailable Paper Type | 2-sided copy could not be performed because the tray does not contain the valid type paper, which are thin, plain, recycled, color, preprinted, prepunched, thick paper 1, or letterhead. | <ul style="list-style-type: none"> ▪ Specify the tray containing the valid type paper in the [Select Paper] setting. See the user's guide. ▪ Specify the valid paper type for the tray selected for printing copies. See the user's guide. |
| Unsupported Device Please Remove | The Scan to USB function failed because a USB device other than a USB flash disk or a USB flash disk with an unsupported file system was used. | Use a USB flash disk that is compatible with the Scan to USB function. |
| Unsupported Device Press Clear key | The Scan to USB function failed because a USB device other than a USB flash disk or a USB flash disk with an unsupported file system was used. | Use a USB flash disk that is compatible with the Scan to USB function. |

Error Messages

| Message | Causes | Solutions |
|-------------------------------------|--|---|
| Unsupported USB Hub Please Remove | The Scan to USB function failed because a USB device other than a USB flash disk or a USB flash disk with an unsupported file system was used. | Use a USB flash disk that is compatible with the Scan to USB function. |
| USB Disconnected Press Clear key | The Scan to USB function failed because the USB flash disk was removed before the operation could be completed. | Check that the USB flash disk is securely inserted in the machine. Do not pull out the USB flash disk until "Ready" appears on the display. |
| USB Memory Overflow Press Clear key | The Scan to USB function failed because there was not enough memory on the USB flash disk. | Use a USB flash disk with enough memory. |
| Write Protect Press Clear key | The Scan to USB function failed because the machine could not access the USB flash disk properly. | Use a USB flash disk that is not password- or write-protected. |

3.2.3 FAX ERROR CODE

This section describes the dial, transmission (TX), and reception (RX) error codes that are printed on the TX Report/Activity Report.

Error codes consist of six hexadecimal digits (0-5).

Digit 5 indicates Fax/Internet Fax and TX/RX.

| Digit 5 (far left) | TX or RX |
|--------------------|-------------------|
| 1xxxxx | TX (Fax) |
| 2xxxxx | RX (Fax) |
| 3xxxxx | TX (Internet Fax) |
| 4xxxxx | RX (Internet Fax) |

Fax Error Code Structure

| Digit 4 | Coding (MH/MR/MMR/JBIG) |
|---------|-------------------------|
| x1xxxx | MH |
| x2xxxx | MR |
| x3xxxx | MMR |
| x4xxxx | JBIG |

| Digit 3 | MODEM mode |
|---------|---------------|
| xx1xxx | V27ter nonECM |
| xx2xxx | V29 nonECM |
| xx3xxx | V17 nonECM |
| xx4xxx | V33 nonECM |
| xx5xxx | V34 |
| xx9xxx | V27ter ECM |

Error Messages

| Digit 3 | MODEM mode |
|-----------------|------------|
| xx a xxx | V29 ECM |
| xx b xxx | V17 ECM |
| xx c xxx | V33 ECM |

| Digit 2 | MODEM speed |
|-----------------|-------------|
| xxx1xx | 2400 |
| xxx2xx | 4800 |
| xxx3xx | 7200 |
| xxx4xx | 9600 |
| xxx5xx | 12000 |
| xxx6xx | 14400 |
| xxx7xx | 16800 |
| xxx8xx | 19200 |
| xxx9xx | 21600 |
| xxx a xx | 24000 |
| xxx b xx | 26400 |
| xxx c xx | 28800 |
| xxx d xx | 31200 |
| xxx e xx | 33600 |

Fax Error Code Table

| Error Code | Error Type | Error Description |
|-------------------------------|---------------------------------|---|
| 0 | General | Normal (No Error) |
| xxxx01 | | STOP |
| Xxxx1f | | H/W Error |
| Not logged in activity report | | RX T1 Time Out |
| 1xxx11 | | Scanner Error during TX |
| 2xxx14 | | Memory Full during RX |
| xxxx06 | | Authorized Reception = Enable, Since received TSI was not match, reception was refused. |
| xxxx21 | Dial failure | Connection Fail |
| xxxx22 | | Dial Fail |
| xxxx23 | | Redial All Failed |
| xxxx31 | Comm. Error 1. Phase-B Error | TX T1 Time Out |
| xxxx32 | | V8 negotiation Fail |
| xxxx40 | Comm. Error 1. Phase-B Error | Retry Out |
| xxxx41 | | Too many FTT |
| xxxx42 | | Too many CRP |
| xxxx43 | | T2 Time Out |
| xxxx44 | | DCN received |
| xxxx45 | | Command Rec Error |
| xxxx46 | | Resp Rec Error |
| xxxx47 | | Invalid Command/Response RX |

Error Messages

| Error Code | Error Type | Error Description |
|------------|---|--|
| xxxx48 | | Remoter No RX capability |
| xxxx49 | | T1 time out after EOM |
| xxxx50 | Comm. Error 2. Phase-C Error | T2 Time Out |
| xxxx51 | | Image Data not ready |
| xxxx52 | | Phase-C Time Out |
| xxxx53 | | JBIG Buffer Full |
| xxxx60 | Comm. Error 3. Phase-D Error | Retry Out |
| xxxx61 | | T2 Time Out |
| xxxx62 | | DCN received |
| xxxx63 | | Too many CRP |
| xxxx64 | | Too many PPR |
| xxxx65 | | RNR time Out |
| xxxx66 | | RTN/PIN Received, EOR/ERR/DCN |
| xxxx67 | | Invalid Command/Response RX |
| xxxx68 | | Command Rec Error |
| xxxx69 | | Resp Rec Error |
| xxxx70 | Comm. Error 4. Phase-E Error | Time Out |
| xxxx80 | Comm. Error 5. Other general Comm Error | modem hang-up |
| xxxx81 | | V34 abort received |
| xxxx82 | | V34 t1 timeout, control channel error |
| xxxx83 | | V34 t1 timeout, primary channel error |
| xxxx84 | | data not sent until guard timer expire |

Internet Fax Error Code Table**Sending Error**

| Error Code | Description | Solution |
|------------|--|---|
| 3xxx11 | Log in error (Connection to the server failed) | Confirm that the network cable is properly connected to the machine. Confirm that the network settings such as IP address, DNS, and SMTP settings have been configured properly (make sure that no double-byte character is used). |
| 3xxx12 | Mail header Edit error (E-mail transmission failed) | Confirm that the network settings such as IP address, DNS, and SMTP settings have been configured properly (make sure that no double-byte character is used). |
| 3xxx13 | Mail part header Edit error (E-mail transmission failed) | Confirm that the network settings such as IP address, DNS, and SMTP settings have been configured properly (make sure that no double-byte character is used). |
| 3xxx14 | Mail part body Edit error (E-mail transmission failed) | Confirm that the network settings such as IP address, DNS, and SMTP settings have been configured properly (make sure that no double-byte character is used). |
| 3xxx31 | Codec error (E-mail transmission failed) | Confirm that the network settings such as IP address, DNS, and SMTP settings have been configured properly (make sure that no double-byte character is used). |
| 3xxx32 | TIFF Edit Error (E-mail transmission failed) | Confirm that the network settings such as IP address, DNS, and SMTP settings have been configured properly (make sure that no double-byte character is used). |
| 3xxx33 | Memory Overflow (The machine memory reached capacity) | The fax was too large. Resend the document in parts as several smaller individual faxes, or send at a lower resolution. |

Receiving Error

| Error Code | Description | Solution |
|------------|--|--|
| 4xxx21 | Log in error (Connection to the server failed) | <p>Confirm that the network cable is properly connected to the machine.</p> <p>Confirm that the network settings such as IP address, DNS, and SMTP settings have been configured properly (make sure that no double-byte character is used).</p> |
| 4xxx22 | E-mail List acquisition error (E-mail reception failed) | Ask the sender to check the e-mail settings. |
| 4xxx23 | Mail header acquisition error (E-mail reception failed) | Ask the sender to check the e-mail settings. |
| 4xxx24 | Mail part header acquisition error (E-mail reception failed) | <p>Ask the sender to check the e-mail settings.</p> <p>The e-mail had an invalid Content-Type, or an unsupported type of file (such as PDF or JPEG) was received. Ask the sender to check the file type.</p> |
| 4xxx25 | Mail part body acquisition error (E-mail reception failed) | Ask the sender to check the e-mail settings. |
| 4xxx26 | Mail part body acquisition error (E-mail reception failed) | There was an error in the received TIFF file (which resulted from a condition not indicated by the error codes 4xxx43 to 4xxx45). Ask the sender to check the TIFF file. |
| 4xxx27 | Mail delete error (E-mail reception failed) | Ask the sender to check the e-mail settings. |

| Error Code | Description | Solution |
|------------|--|---|
| 4xxx41 | Invalid mail header (E-mail reception failed) | Ask the sender to check the e-mail settings. |
| 4xxx42 | Invalid part header (E-mail reception failed) | Ask the sender to check the e-mail settings. |
| 4xxx43 | Codec Error (A TIFF file could not be received properly.) | The compression method of the received TIFF file was other than MH/MR/MMR. Ask the sender to check the TIFF file. |
| 4xxx44 | TIFF over spec (A TIFF file could not be received properly.) | The resolution of the TIFF file was not supported, or the width of the TIFF file was A3 or B4. Ask the sender to check the TIFF file. |
| 4xxx45 | TIFF Form abnormal (A TIFF file could not be received properly.) | The format of the TIFF file was other than TIFF-S/F. Ask the sender to check the TIFF file. |
| 4xxx46 | Memory Overflow (The machine memory reached capacity) | The fax was too large. Ask the sender to resend the document in parts as several smaller individual faxes, or send at a lower resolution. |

(M355)

PAPER FEED UNIT TK 1080

| REVISION HISTORY | | |
|-------------------------|-------------|--------------------------|
| Page | Date | Added/Updated/New |
| | | None |

(M355) Paper Feed Unit TK 1080

TABLE OF CONTENTS

| | |
|--|------------|
| 1. REPLACEMENT AND ADJUSTMENT | 1-1 |
| 1.1 EXTERNAL COVERS AND PAPER FEED UNIT..... | 1-1 |
| 1.1.1 REAR COVER | 1-1 |
| 1.1.2 RIGHT COVER | 1-2 |
| 1.1.3 PAPER FEED UNIT | 1-2 |
| 1.2 PAPER FEED ROLLER | 1-4 |
| 1.2.1 PAPER FEED ROLLER | 1-4 |
| 1.3 FRICTION PAD..... | 1-6 |
| 1.3.1 FRICTION PAD..... | 1-6 |
| 1.4 PAPER FEED MOTOR AND GEARS | 1-7 |
| 1.4.1 PAPER FEED MOTOR | 1-7 |
| 1.4.2 PAPER FEED GEARS..... | 1-8 |
| 1.5 PAPER TRAY BOARD..... | 1-9 |
| 1.5.1 PAPER TRAY BOARD..... | 1-9 |
| 1.6 PAPER TRAY UNIT SET SWITCH..... | 1-10 |
| 1.6.1 PAPER TRAY UNIT SET SWITCH..... | 1-10 |
| 1.7 SENSORS..... | 1-11 |
| 1.7.1 PAPER FEED SENSOR | 1-11 |
| 1.7.2 PAPER END SENSOR | 1-11 |

Read This First

Safety and Symbols

Replacement Procedure Safety

CAUTION

- Turn off the main power switch and unplug the machine before beginning any of the replacement procedures in this manual.

Symbols Used in this Manual

This manual uses the following symbols.

: See or Refer to

: Screws

: Connector

: Clamp

: Clip ring

 : E-ring

REPLACEMENT AND ADJUSTMENT

1. REPLACEMENT AND ADJUSTMENT


1.1 EXTERNAL COVERS AND PAPER FEED UNIT

CAUTION

- Turn off the main power switch and unplug the machine before attempting any procedure in this section.

1.1.1 REAR COVER

1. Remove the paper tray unit from the main unit.
2. Pull out the paper tray.




m355r500

3. Rear cover [A] ( x2).

1.1.2 RIGHT COVER

1. Rear cover (📄 1-1)




m355r501

2. Right cover [A] (🔩 x2).

1.1.3 PAPER FEED UNIT


1. Right cover (📄 p.1-2)
2. Paper feed motor bracket (📄 p.1-8)



m355r502


3. Paper feed roller shaft gear [A] (C-ring x1)

External Covers and Paper Feed Unit



m355r503

4. Release paper feed roller shaft [A] (C-ring x1, bushing x1).



m355r505

5. Paper feed unit [A] (🔩 x4)


Paper Feed
Unit TK1080
(M355)

1.2 PAPER FEED ROLLER

1.2.1 PAPER FEED ROLLER

Remove the paper feed roller

1. Right cover (p.1-2).




m355r510




m355r511

2. Remove a C-ring [A] and a bushing [B].



m355r512

3. Release the paper feed roller shaft [A].




m355r513

4. Release the hook [A] and then move the paper feed roller [B] to the right.

Reinstall the paper feed roller

1. Attach the paper feed roller to the paper feed roller shaft.



m355r514

m355r515

2. Reinstall the paper feed roller shaft correctly.


↓ Note

- As shown in the above pictures, the paper feed roller shaft must be installed behind the feeler [A]. The left picture [B] is correct. The right picture [C] is incorrect.
3. Close the right cover first, and then close the rear cover.


1.3 FRICTION PAD

1.3.1 FRICTION PAD

1. Pull out the paper tray.



m355r516




m355r517

2. Turn the paper feed unit over, and release two hooks [A].
3. Turn the unit over again, and remove the friction pad [B].

1.4 PAPER FEED MOTOR AND GEARS

1.4.1 PAPER FEED MOTOR

1. Right cover (🔧 p.1-2)




m355r520

2. Paper feed motor [A] (🔧 x2, 📎 x1, 📎 x1)


1.4.2 PAPER FEED GEARS

1. Right cover (🔧 p.1-2)



m355r521

2. Paper feed motor bracket [A] (🔧 x3, 🛠️ x1, 🛠️ x1)




m355r522

3. Paper feed gears [A] (each C-ring x1)

1.5 PAPER TRAY BOARD

1.5.1 PAPER TRAY BOARD

1. Right cover (📄 p.1-2)




m355r530

2. Paper Tray Board (📄 x2, locking support x2, 📄 x 4)

1.6 PAPER TRAY UNIT SET SWITCH


1.6.1 PAPER TRAY UNIT SET SWITCH

1. Paper feed unit (☞ p.1-2)




m355r540

2. Feeler [A]



m355r541




m355r542

3. Paper tray unit set switch [A] (hook x2)

1.7 SENSORS

1.7.1 PAPER FEED SENSOR


1. Right cover (🔧 p.1-2)



2. Release the actuator [A] from the slot of the paper feed sensor [B]
3. Paper feed sensor [B] (all hooks, 🛠️ x1)

1.7.2 PAPER END SENSOR

1. Right cover (🔧 p.1-2)



2. Release the actuator [A] from the slot of the paper exit sensor [B]
3. Paper end sensor [B] (all hooks, 🛠️ x1)